

HOT SHOT



PLACE SERIAL NUMBER LABEL HERE

FACTORY CONTACT INFORMATION



BAY TEK ENTERTAINMENT INC.
Pulaski Industrial Park
1077 East. Glenbrook Drive
Pulaski, WI 54162 USA

JOIN OUR SERVICE FIRST NETWORK!

This free service is intended to keep you up to date on the latest game information, early notification of parts specials, pertinent technical bulletins, updates on retro fit parts, software upgrades, and much more.

Log on to: <http://www.baytekent.com/parts-services/>
then click on the Parts N' Service tab.

SALES

P: 920.822.3951

F: 920.822.8936

E: sales@baytekent.com

PARTS

P: 920.822.3951 X 1101

F: 920.822.1496

E: parts@baytekent.com

SERVICE

P: 920.822.3951 X 1102

F: 920.822.1496

E: service@baytekent.com

MON - FRI
8 AM - 5 PM C.S.T.

All games are proudly manufactured at our factory in Pulaski, Wisconsin, USA

TABLE OF CONTENTS

FACTORY CONTACT INFORMATION	2
WELCOME TO: Hot Shot	4
HOW TO PLAY	5
SPECIFICATIONS	6
SAFETY PRECAUTIONS	6
SET UP GUIDE	7-25
SKID STACKING DIAGRAM	26
DIP SWITCH SETTINGS	27
MAIN MENU FUNCTIONS	28
CREDITS PER PLAY	29
ATTRACT VOLUME	29
GAME VOLUME	29
ATTRACT TIMING	29
JOIN IN TIME DELAY	30
GAME LENGTH	30
THREE POINT TIME	30
POINTS NEEDED FOR BONUS TIME	31
BONUS TIME REWARDED	31
BONUS TIME MODE	31
POINTS PER TICKET	32
DOUBLE TICKETS	32
MINIMUM TICKETS PER GAME	32
MINIMUM HIGH SCORE	33
HIGH SCORE RESET	33
RESET SETTINGS	33
CIRCUIT BOARD PINOUTS	34-36
WIRING DIAGRAMS	37-39
TROUBLESHOOTING GUIDE	40-47
HOW TO: UPDATE SOFTWARE	48
OPTIONAL GAME DIVIDERS	49-57
PARTS LIST	58
PARTS PICTURES	59
MAINTENANCE LOG	60
TECHNICAL SUPPORT	61
WARRANTY	62

WELCOME TO: Hot Shot

Congratulations on your Hot Shot purchase!

This enormous, full-sized basketball game will become the focal point of your game room! With it's 10 foot high, regulation sized rim, official free throw distance and professional basketballs, sports enthusiasts will enjoy decades of entertainment value!

Please take a moment to read through this manual and be sure to contact our factory if you have any questions, or would like some more information.

Thank you for your purchase! Your business is important to us and we hope you enjoy this game as much as we do!

Your Friends at Bay Tek Games



GAME INSPECTION

Inspect the game for any damaged, loose, or missing parts.

If damage is found, please contact your freight carrier first.

Then, contact Bay Tek Games' Service Department at 920.822.3951 or e-mail them at service@baytekgames.com for further assistance.

HOW TO PLAY

Insert credits and select game play:
GROUP play or SOLO play



Shoot as many balls as you can in the allotted time and make them in the hoop to score points!



Win tickets for points scored!
(If ticket payout is enabled)



GAME SPECIFICATIONS

WEIGHT	
NET WEIGHT	3,300 LBS.
SHIP WEIGHT	3,500 LBS.
DIMENSIONS	
WIDTH	65"
DEPTH	166"
HEIGHT	162"
OPERATING TEMPERATURE	
FAHRENHEIT	80-100
CELSIUS	26.7-37.8

POWER REQUIREMENTS			
INPUT VOLTAGE RANGE	100 to 120 VAC	/	220 to 240 VAC
INPUT FREQUENCY RANGE	50 HZ	/	60 HZ

MAX OPERATING CURRENT	
1.4 AMPS @ 115 VAC	
.8 AMPS @ 230 VAC	

SAFETY PRECAUTIONS

NOTICE	
<p>Modifications to the mechanical, electrical and structural components of this game may void its compliance certifications.</p> <p>This appliance is suitable for INDOOR, DRY locations only.</p>	
DANGER	
<p>DO NOT perform repairs or maintenance on this game with the power ON. Unplug the unit from the wall outlet or shut off the power strip located inside the cabinet.</p>	
WARNING	
<p>Use of flammable substances can cause sever burns or serious injury. Always use NON-FLAMMABLE solvents for cleaning. DO NOT use gasoline kerosene or thinners.</p>	
CAUTION	
<p>Lifting heavy objects can cause back, neck or other injuries. Be sure adequate lifting and moving devices are available when unloading, unpacking and moving this game.</p>	
ATTENTION	
<p>Be sure the electrical power matches the game requirements. See the serial number located on the back of the game cabinet. Always plug into a grounded circuit. If the supply cord is damaged, it must be replaced by an approved cord or assembly provided by the manufacturer.</p> <p>A shielded power cable must be used for the game to retain EU/EMC compliance.</p>	
IN CASE OF EMERGENCY	
<p>UNPLUG THE POWER CORD.</p> <p>The power cord must be accessible at all times in case of an emergency.</p>	

SET UP GUIDE

****THE GAME PARTS ARE STACKED IN CHRONOLOGICAL BUILD ORDER ON THE SKIDS. FOR EASE OF ASSEMBLY, DO NOT REMOVE THE PARTS FROM THE SKIDS PRIOR TO THEIR NEEDED USE.**

(See Skid Stacking Diagram on page 26).

NEEDED FOR GAME ASSEMBLY:

- 3/8" socket
- 9/16" socket
- #3 phillips
- Exacto knife
- Side cutter
- 2 - 12' ladders
- Earmuffs
- 2-3 strong people

Place skids in close location to where the game will be set up. Be sure to not place pallets in direct location of the final assembled game position.



Using the side cutter, carefully cut the metal banding around the skids. Remove the bands and properly discard.



Using the exacto knife, carefully cut the plastic wrap around the skids. Remove the wrap and cardboard corners from the skids. Properly discard.

SET UP GUIDE

With assistance, lift and remove the BACKBOARD ASSEMBLY off of [SKID 1]. Set off to the side for later installation.



Lift and remove PANEL 2 (lower side rear) from [SKID 1]. This will be the bottom left side piece so place this where the left rear of your game will be - flush side out.



From [SKID 2] lift and remove PANEL 1 (bottom back). This will be the bottom back piece so place it next to the left side as shown - flush side in.

Secure the pieces together in the rear using the included lock nuts (#93298A130) (2).



SET UP GUIDE

Lift and remove the other PANEL 2 (lower side rear) from the [SKID 1]. This will be the bottom right side piece - install with flush side out.



Secure the pieces together in the rear using the included lock nuts (#93298A130) (2).



Lift and remove PANEL 3 (lower back) from the [SKID 2]. Install with the printed "crowd" graphic to the inside of the game.



Be sure the tabs on the bottom of the lower back piece slide to the OUTSIDE of the bottom back. (These help to stabilize the pieces)



Secure the backboard to the side pieces using the included lock nuts (#93298A130) (4).



SET UP GUIDE

Thread in the included bolts/nuts (#92979A344) (4) into both sides - thread them in as far as you can.




Lift PANEL 4 (ramp) from [SKID 2] and set onto the bolts threaded on each side.



*****it is recommended to wear earmuffs while performing this step*****

Secure the ramp piece in place from underneath, by tightening the nuts already on the bolts.



SET UP GUIDE


From [SKID 1], lift and Install PANEL 5 (lower side) piece - install with flush side out.

Secure pieces together with included lock nuts (#93298A130) (2).

Repeat above steps to install another PANEL 5 (lower side) from [SKID 1] to the right side.



Thread in the included bolts/nuts (#92979A344) (4) into both sides - thread them in as far as you can.



Lift and place a PANEL 4 (ramp) piece from [SKID 2] onto the bolts threaded on each side.

Secure the floor/ramp piece in place from underneath by tightening the nuts already on the bolts. *****Use ear muffs when tightening!***




SET UP GUIDE


Lift a PANEL 5 (lower side) piece from [SKID 1] and install to the left side of the game - install with flush side out.

Secure pieces together with included lock nuts (#93298A130) (2).

Repeat above steps to install the last PANEL 5 (lower side) from [SKID 1] to the right side of the game. Secure with the lock nuts (#93298A130) (2).



Thread in the included bolts/nuts (#92979A344) (4) into both sides - thread them in as far as you can.



Lift and place the last PANEL 4 (ramp) piece from [SKID 2] and onto the bolts threaded on each side.

Secure the floor/ramp piece in place from underneath by tightening the nuts already on the bolts. ****Use ear muffs when tightening!**



SET UP GUIDE

From [SKID 2], lift and carefully place PANEL 6 (middle back) onto the ramp.




Use a ladder to safely step up onto the floor boards/ramp.



Lift and place PANEL 6 on top of the bottom back - install with the printed "crowd" graphic to the inside of the game.

Be sure the tabs on the bottom back of PANEL 6 slide to the INSIDE of the brackets on the bottom back. (These help to stabilize the pieces)



SET UP GUIDE


Carefully lift and place PANEL 7 (upper rear net) from [SKID 1] on top of the lower right side rear panel.

****ALL NET PANELS WILL BE PLACED WITH CUT OUTS TO THE INSIDE OF THE CABINET. THE NETTING AND OUTSIDE RAILS WILL SIT FLUSH TO THE OUTSIDE OF THE CABINET!**

Secure the piece to the back board using the included nuts (#93298A130) (2).

Also secure the yellow net piece to the bottom black panel using the same included nuts (2).

Repeat above steps to install the left side PANEL 7 (upper rear net) from [SKID 1] on top of the lower left side rear panel.



Carefully lift and place PANEL 8 (upper net) from [SKID 1] on top of the right middle lower side panel, next to the already installed upper net.

Secure the two net pieces together by tightening a nut (#93298A130) onto the stud.


Also secure the net piece to the bottom black panel using the same nuts (2.)



SET UP GUIDE

Repeat previous steps to install left side
PANEL 7 and PANEL 8 netted sides.

You should have four upper net pieces
installed as shown in the picture.



Carefully lift and place another
PANEL 8 from [SKID 1] on top of the
front left black side panel.

Secure the front piece to the
middle net piece by tightening a nut
(#93298A130) onto the stud.

Also secure the front piece to the
bottom black panel using the same
nuts (2.)



SET UP GUIDE

Repeat previous steps to install front right side PANEL 8 yellow netted side.

You should have all six of the yellow netted pieces installed now as shown in the picture.




Place both 12' ladders at the rear of the game.

Set the impact with the 9/16" socket on, on top of one of the ladders.

Place two flanged bolts (#92979A344) on top of each ladder, in an easily accessible place.

Lift and remove PANEL 9 (upper back) from [SKID 2] and carefully walk it up the ladders.

Install the piece with the printed "crowd" graphic to the inside of the game.



SET UP GUIDE


Once the upper back is installed and in place, secure using the bolts placed on top of the ladders earlier.



Leave one of the ladders at the rear of the game.

Place the other ladder at the front of the game.

Carefully lift and place the backboard assembly up onto the ramp.




SET UP GUIDE

Use the ladder to climb up onto the ramp.

Lift and install the backboard assembly into the cut outs on the backboard. (A third person may be required to help pull the wires through the back board as it is being installed. They can stand on the ladder in the rear of the game and feed the wires through the cutout.) Be cautious to not pinch the wires!

Secure the backboard assembly in place using the 4pc backboard mounting bolts (#92979A352).



SET UP GUIDE

Next you will install the most rear top net piece - place both ladders at the rear outsides of the game.

Walk the top net piece (4028-10330) from [SKID 2] up the ladder and slide it into position best you can. Secure one side to the studs, then shift and adjust the other side until in place.

Once both sides are in place, secure using the included nuts (#93298A130).



Carefully lifting the other two top net pieces from [SKID 2] and up the ladder Stack on top of the already installed net.



Move the ladders to have one on each side of the game. Carefully install and secure the remaining two top net pieces with the same sequence used for the first. Move the ladders accordingly for best access.



SET UP GUIDE


Remove the packaging and wrapping of the floor foam, brackets and “wood grain” overlay.



Lay the foam onto the ramp. Leave approximately 1” of space between the back board and the foam edge.



Carefully lay the “wood grain” over the foam with the flat end to the back board.



SET UP GUIDE

Start with securing the rear of the wood grain to the floor/ramp using the included 'carpet hold' screws (#91715A168). Use the bracket with the round holes (not the slotted holes).



Secure the sides of the wood grain to the floor/ramp using the same included screws as used for the rear bracket. Use the brackets with the slotted holes for the sides.

*****DO NOT tighten the screws down all the way, you will bend the brackets but make the screws tight enough to hold in place.***




Place the console in front of the ramp.

Remove the plastic wrap from around the console. Use the side cuts to cut the metal banding. Remove the banding and any cardboard and foam - discard.




SET UP GUIDE

Carefully slide the console off the skid and place it by the ramp. Lift the wood grain up before sliding the console all the way back.




Climb inside the console and secure the console to the ramp using the included nuts (#93298A130) (4). *****Use ear muffs when tightening bolts!***



While inside the console, route cables CE9414, CE9412 and the power cable from the front of the console to the rear.

SET UP GUIDE

Unpackage the ball stop rails. Install and secure them in place using the included bolts (#94239A100) in the bottoms (4 total) and bolts (#92979A344) up the sides (4 total).



Unpackage the ball guides. Install and secure them in place using the included bolts (#94239A100).



SET UP GUIDE




Secure the front of the wood grain down using the black rail and the same 'carpet hold' screws (#91715A168)



Route cables CE9414 and CE9412 from the bottom of the game up towards the hoop lights and sensor cables.

Plug in the sensor cables to CE9412, matching the colors: yellow to yellow and brown to brown.

Plug in the hoop lights cable to CE9414.




Feed an excess cabling back down into the inside of the cabinet.

SET UP GUIDE

Plug the power cord into a standard electrical outlet.

Turn the power strip inside the front door to ON.




Locate clear rectangle plastic. Carefully peel off protective file. Center on seam of crowd graphic with countersinks of holes facing away from the graphic and up.

Being extremely careful not to overtighten the supplied wood screws, screw plastic onto crowd graphic through holes that are provided in plastic.




You're ready to HOT SHOT!




SKID STACKING DIAGRAM


- A5KIT-HS-SKID3**
- PACKAGE AS SHOWN (SEE CORNER DETAIL VIEW)
 - PANEL STACK AND BLOCKING MUST BE STRAIGHT AND IN LINE
 - WRAP CARPET HOLDS IN FOAM AND PLACE INSIDE CONSOLE
 - PLACE BALLS IN S-5347 BAG AND SET ON RAMP
 - WRAP BALL GUIDES IN FOAM AND SET ON RAMP
 - USE PLASTIC BANDING
 - SECURE 22.5-15 BAG OVER CONSOLE AFTER BANDING
 - LABEL AS SKID 3 USING BLANK LABEL



- A5KIT-HS-SKID2**
- PACKAGE AS SHOWN (SEE CORNER DETAIL VIEW)
 - PANEL STACK AND BLOCKING MUST BE STRAIGHT AND IN LINE
 - PROTECT BALL GUARDS FROM CARPET WITH FOAM/CARDBOARD
 - USE PLASTIC BANDING
 - LABEL AS SKID 2 USING BLANK LABEL



- A5KIT-HS-SKID1**
- PACKAGE AS SHOWN (SEE CORNER DETAIL VIEW)
 - PANEL STACK AND BLOCKING MUST BE STRAIGHT AND IN LINE
 - PROTECT BACKBOARD WITH FOAM & CARDBOARD PRIOR TO BANDING
 - USE PLASTIC BANDING
 - LABEL AS SKID 1 USING BLANK LABEL



SKID 3

QTY.	PANEL #	DESCRIPTION
1	NA	CONSOLE ASSEMBLY

SKID 2

QTY.	PANEL #	DESCRIPTION
1	NA	FLOOR, FOAM & LAMINATE PACKAGED
2	NA	ASSEMBLY, HOT SHOT
1	1	WMT, BOTTOM BACK
1	3	ASM, LOWER BACK
3	4	ASM, CAGE RAMP
1	6	ASM, MIDDLE BACK
1	9	ASM, MIDDLE BACK
3	NA	ASM, TOP NET

SKID 1

QTY.	PANEL #	DESCRIPTION
1	NA	BACKBOARD ASSEMBLY
2	2	WMT, LOWER SIDE REAR
4	5	WMT, LOWER SIDE
2	7	ASM, UPPER REAR NET
4	8	ASM, UPPER NET

DIP SWITCH SETTINGS

The dip switch bank is located on the mainboard,
inside the front door of the game.

*factory default settings are highlighted below

SWITCH	DESCRIPTION	ON	OFF
1	NEW JERSEY		X
2			
3			
4	MANUFACTURER SETTINGS	X	

MAIN MENU FUNCTIONS

Press and hold the MENU button to enter the game menu.

Scroll through each sub-menu with the MENU SELECT button.

Press MENU to move to the next sub-menu.



MENU	DESCRIPTION
N1	CREDITS PER PLAY
N2	ATTRACT VOLUME
N3	GAME VOLUME
N4	ATTRACT TIMING
N5	JOIN IN TIME DELAY
N6	GAME LENGTH
N7	THREE POINT TIME
N8	POINTS NEEDED FOR BONUS TIME
N9	BONUS TIME AWARDED
N10	BONUS TIME MODE
N11	POINTS PER TICKET
N12	DOUBLE TICKETS
N13	MINIMUM TICKETS PER GAME
N14	MINIMUM HIGH SCORE
N15	HIGH SCORE RESET
N16	RESET SETTINGS

N1- CREDITS PER PLAY

Scroll through the N1 menu with the “MENU” button.
Make your selection with the “SELECT” button.
The factory settings are highlighted below.

ADJUSTABLE IN INCREMENTS OF 1			
0	TO	20	4 DEFAULT

N2- ATTRACT VOLUME

Scroll through the N2 menu with the “MENU” button.
Make your selection with the “SELECT” button.
The factory settings are highlighted below.

0	1	2	3	4	5	6	7	8	9	10
---	---	---	---	----------	---	---	---	---	---	----

N3- GAME VOLUME

Scroll through the N3 menu with the “MENU” button.
Make your selection with the “SELECT” button.
The factory settings are highlighted below.

0	1	2	3	4	5	6	7	8	9	10
---	---	---	---	---	---	----------	---	---	---	----

N4- ATTRACT TIMING

Scroll through the N4 menu with the “MENU” button.
Make your selection with the “SELECT” button.
The factory settings are highlighted below.

This setting determines how often the attract audio loop is played.

0	1	2	3	4	5	6	7	8	9	10
in minutes										

N5- JOIN IN TIME DELAY

Scroll through the N5 menu with the “MENU” button.
Make your selection with the “SELECT” button.
The factory settings are highlighted below.

This setting determines how much time additional players have to credit and join in game play once a competition is started by the first player. Game will automatically start after the set amount of time is reached.

ADJUSTABLE IN INCREMENTS OF 1			
5	TO	15	10 DEFAULT
in seconds			

N6- GAME LENGTH

Scroll through the N6 menu with the “MENU” button.
Make your selection with the “SELECT” button.
The factory settings are highlighted below.

This option sets the base time for game play.

ADJUSTABLE IN INCREMENTS OF 5			
15	TO	85	45 DEFAULT
in seconds			

N7- THREE POINT TIME

Scroll through the N7 menu with the “MENU” button.
Make your selection with the “SELECT” button.
The factory settings are highlighted below.

This option sets the period of time that each made basket is worth 3 points.

ADJUSTABLE IN INCREMENTS OF 1			
0 (disabled)	TO	30	5 DEFAULT
in seconds			

N8- POINTS NEEDED FOR BONUS TIME

Scroll through the N8 menu with the “MENU” button.
Make your selection with the “SELECT” button.
The factory settings are highlighted below.

This setting determines the amount of points needed to be scored during regular game play to receive the additional bonus time.

ADJUSTABLE IN INCREMENTS OF 5			
0	TO	65	20 DEFAULT

N9- BONUS TIME REWARDED

Scroll through the N9 menu with the “MENU” button.
Make your selection with the “SELECT” button.
The factory settings are highlighted below.

This will set the amount of bonus time awarded to a player who scores the required amount of points.

ADJUSTABLE IN INCREMENTS OF 1			
0 (disabled)	TO	25	5 DEFAULT
in seconds			

N10- BONUS TIME MODE

This option allows the player to get additional playing time.

OFF: No additional time can be earned

EVERY XX POINTS: In this mode a player will receive extra time every XX points (see “points needed for bonus time”) NOTE: in this mode, all tournament players get additional time each time any of the players gets additional time.

ONCE: The player can get extra time, but only once.

OFF	EVERY XX POINTS	ONCE
------------	----------------------------	-------------

N11- POINTS PER TICKET

Scroll through the N11 menu with the “MENU” button.
Make your selection with the “SELECT” button.
The factory settings are highlighted below.

This mode determines how many points are needed to dispense 1 ticket. EX: if ‘3’ is set, then for every 3 points scored, 1 ticket will be dispensed. Setting ‘0’ turns this option off and is an amusement only game play.

0 DEFAULT	ADJUSTABLE IN INCREMENTS OF 1		
	0 (non-redemption mode)	TO	10
	ADJUSTABLE IN INCREMENTS OF 2		
	12	TO	20
	ADJUSTABLE IN INCREMENTS OF 5		
	25	TO	50

N12- DOUBLE TICKETS

Scroll through the N12 menu with the “MENU” button.
Make your selection with the “SELECT” button.
The factory settings are highlighted below.

If each physical ticket has a value of 2, turn this option to YES.

NO	YES
-----------	------------

N13- MINIMUM TICKETS PER GAME

Scroll through the N13 menu with the “MENU” button.
Make your selection with the “SELECT” button.
The factory settings are highlighted below.

This will set the minimum amount of tickets a player will win regardless of how many points they score or how other ticket options in the game might be set.

ADJUSTABLE IN INCREMENTS OF 1			
0 (disabled)	TO	10	0 DEFAULT

N14- MINIMUM HIGH SCORE

Scroll through the N14 menu with the “MENU” button.
Make your selection with the “SELECT” button.
The factory settings are highlighted below.

This option will set the starting minimum score needed to win the jackpot amount.

60 DEFAULT	ADJUSTABLE IN INCREMENTS OF 1		
	0	TO	10
	ADJUSTABLE IN INCREMENTS OF 2		
	12	TO	30
	ADJUSTABLE IN INCREMENTS OF 5		
	35	TO	50
	ADJUSTABLE IN INCREMENTS OF 10		
	60	TO	180


N15- HIGH SCORE RESET

Press the MENU SELECT button 3 times to clear the current high score and reset to the minimum high score.


N16- RESET SETTINGS

Press the MENU SELECT button 3 times to reset all settings to the factory defaults.

MAIN BOARD PINOUT




- SPI Out - Display - (J10)
- Pin 1 & Pin 3 - +12V
- Pin 2 - SCLK_BUS2
- Pin 4 - SMOSI_BUS2
- Pin 5 & Pin 7 - Ground
- Pin 6 - SCS2_BUS2
- Pin 8 - SMISO_BUS2



- Chase Lights (J11,J12,J13,J14)
- Pin 1 - Chase Output
- Pin 2 - Chase Output
- Pin 3 - +12V
- Pin 4 - Chase Output
- Pin 5 - Chase Output
- Pin 6 - +12V


- Ground
- +12V
- Low Side Driver
- High Side Driver
- TTL Logic
- +3.3V

AANEWGEN1-RBN PINOUT




WIRING DIAGRAM

POWER, POWER SUPPLY & DISPLAY




WIRING DIAGRAM

COIN DOOR, BALL GATE, LOW TICKET & PUSH BUTTONS



WIRING DIAGRAM

DISPENSERS, MENU BUTTONS, COUNTERS, HOOP SENSORS & SPEAKER



TROUBLESHOOTING GUIDE

Problem	Probable Cause	Remedy
No power to the game.	Unplugged. Power strip turned off, or plugs unplugged. Circuit breaker tripped. Line filter faulty. Bad or overloaded power supply.	Check wall outlet cable (A5CORD29) to line filter in front of game. (A5FI9010) Check rocker switch on power strip. Ensure power cords are pushed up into power strip securely. Reset power strip breaker switch or building circuit breaker. Attempt to determine cause. Replace line filter. (A5FI9010) Refer to Power Supply Diagnostics
Bill Acceptor on, but everything else off. (Power Supply not ON)	Power supply unplugged. Rocker Switch on power supply is Off. Power supply shutting down because of 12 V overload. Faulty power supply.	Insure unit is plugged into power strip. Make sure rocker switch is set ON. See power supply diagnostics to isolate bad component. A bad motor or 12 volt short would cause this. Refer to Power Supply Diagnostics section.
LED cabinet lighting not working.	LED's to light up playfield plug into power supply. Faulty LED Light	Check for proper connection from power supply to LEDs. Check continuity. (AACE9421, AACE9401, AAPS1013-HS) Refer to Wiring Diagram section. Replace AACE9421
LED lighting around backboard not working. The LEDs should flash when shot is scored.	The LEDs should flash when shot is scored. Faulty wire or connection. Faulty 12 V LED light strip Faulty main board.	Ensure hoop is scoring, if not - refer to Scoring Issues section. Check for proper connection from LED's to main board. Check continuity. Check for damaged wire or connector. Refer to Wiring Diagram section. (AACO9400, AACE9414) Replace LED light strip. (AACO9400) Replace main board. (AANEWGEN1-RBN)
Menu buttons do not work.	Stuck pushbutton. Cable problem. Faulty pushbutton.	Inspect pushbutton to make sure it is not stuck. Check continuity on connector. Check cable from pushbutton to main board. (AAPB2700 & AACE9406) Replace pushbutton. (AAPB2700)

TROUBLESHOOTING GUIDE

Problem	Probable Cause	Remedy
<p>Dollar Bill Acceptor not functioning.</p>	<p>Ensure bill acceptor has 110 Volts AC.</p> <p>Dirt or debris in acceptor slot.</p> <p>Ensure acceptor dipswitch is set to “always enable”</p> <p>Pinched, broken, or disconnected wiring.</p> <p>Bill acceptor problem.</p>	<p>Acceptor should cycle stacker at game power up. If not, check cable connections to power strip. Caution – 110 Volts AC</p> <p>Clean with bill reader cleaning card. (A5CC9000)</p> <p>There are dips on side of acceptor. Set to “always enable” (not harness enable)</p> <p>Check wiring from bill acceptor to main board. Repair or replace wiring harness. (AACE9408)</p> <p>Refer to troubleshooting section of dollar bill acceptor manual included with this game or the diagnostics label of the back of the unit.</p>
<p>No Audio</p>	<p>Volume too low.</p> <p>Loose wire.</p> <p>Faulty Main Board</p>	<p>Increase the volume by pressing Menu button, to “Game Volume”</p> <p>Check audio cable connections from main board to speakers. (AACE8811, AACE9404, AANEWGEN1-RBN)</p> <p>Replace Main Board. (AANEWGEN1-RBN)</p>
<p>Display not working</p> <p>Note: Some games may have a Booster Board (Part # AACB6401)</p>	<p>1/2 of display is not working</p>	<p>There are 2 display boards in line. Remove front plexi and inspect: Ribbon cable between display modules. (A5CE9421) 5 Volt power in from first board. (AACE9419) Replace display module (A5LD1052)</p>
<p>Entire display is not working or fuzzy</p>	<p>5 Volt power In is missing from Jackpot Display or Booster Board</p> <p>Communication cable issue.</p>	<p>Check cables from display boards to power supply. (AACE9419, AACE9418, AACE9400, AACE9735, & AAPS1013-HS for display) (AACE9734 & AACE3735 for Booster Board)</p> <p>Reseat ribbon cable from display boards to main board (AACE9415, AACE9736, & AACE9417)</p> <p>Swap 1st board with the 2nd board to identify a problem display board. Replace display A5LD1052 if needed.</p>
<p>Low tickets Icon shows on display</p> 	<p>Stack of tickets not resting properly on either of the low ticket switches</p> <p>Faulty switch.</p> <p>Faulty wire or connection.</p> <p>Faulty main board.</p>	<p>Adjust stack of tickets so they hold both the switch actuators down.</p> <p>Replace low ticket switch. (AASW200)</p> <p>Check for proper connection from switch to main board. Check continuity. (AACE9402)</p> <p>Replace main board. (AANEWGEN1-RBN)</p>


TROUBLESHOOTING GUIDE

Symptom	Probable Cause	Remedy
<p>Tickets do not dispense.</p>	<p>Ticket tray empty due to faulty low ticket switch or broken/ loose wires. Switch stuck or switch wire bent out of position.</p> <p>Faulty cable to dispenser.</p> <p>Dirty opto-sensor or paper dust buildup in ticket dispenser</p> <p>Notch on tickets too shallow.</p> <p>Ticket dispenser faulty.</p> <p>Main circuit board malfunction.</p>	<p>Fill ticket tray. Replace low ticket switch(AASW200). Repair wiring. Clean ticket tray of dirt, loose tickets or debris. Bend switch wire to correct position under tickets.</p> <p>Check wiring continuity from dispenser to main board (AACE9403) Check for pinched, broken or disconnected wires. Replace as necessary.</p> <p>Clean with compressed air and if necessary wipe sensor with isopropyl alcohol on a cotton swab.</p> <p>Flip tickets and load upside-down to have large cut notch toward opto sensor.</p> <p>Replace dispenser with spare working dispenser (A5TD1)</p> <p>Swap cable from one output (J5) on main board to the other (J9) to verify cable/dispenser problem or faulty main board. (AANEWGEN1-RBN)</p>
<p>Wrong number of tickets dispensed.</p>	<p>Ticket Pattern set wrong.</p> <p>Dirty opto-sensor on ticket dispenser.</p> <p>Notch on tickets cut too shallow.</p> <p>Faulty ticket dispenser.</p> <p>Main circuit board malfunction.</p>	<p>Enter menu and verify desired points per tickets.</p> <p>Clean with compressed air or wipe with isopropyl alcohol on a cotton swab.</p> <p>Flip tickets and load upside-down to have large cut notch toward opto sensor.</p> <p>Replace with spare working dispenser (A5TD1).</p> <p>Swap cable from one output (J5) on main board to the other (J9) to verify cable/dispenser problem or faulty main board. (AANEWGEN1-RBN)</p>
<p>Game scores wrong.</p>	<p>Scoring optos misaligned or faulty.</p>	<p>Refer to “Scoring Issues” troubleshooting section.</p>
<p>Game does not coin up.</p> <p>Game should have an audio track sound from speakers when coin switch triggered.</p>	<p>One or both coin switches faulty.</p> <p>Pinched, broken, or disconnected wiring.</p> <p>Check Power In to Main Board</p> <p>Faulty Main Board</p>	<p>If one is held “closed” - the other will not work</p> <p>Check connections from coin switches to “Coin” connector on main board. Check continuity on wires. (AACBL4A-DOOR & AACE9402)</p> <p>Check connections from power supply to main board. Check continuity on wires.(AACE9413) Refer to Power Supply Diagnostics section.</p> <p>Replace main board. (AANEWGEN1-RBN)</p>

TROUBLESHOOTING GUIDE

Problem	Probable Cause	Remedy
Lights under Solo & Group Pushbuttons do not come on.	Burnt out LED bulb. Faulty Cable Faulty Main Board	Replace switch/bulb assy(A5LA1003) Check cables from pushbutton to main board. (AACE9402) Refer to Wiring Diagram to ensure correct wire is on correct terminal. Replace main board. (AANEWGEN-RBN)
Lights under Solo & Group Pushbuttons stays on.	Surface mounted transistor blown on main board.	Replace main board. (AANEWGEN-RBN)
Solo & Group Pushbuttons do not work.	Pushbutton itself is broken or stuck down Enter menu and check Diagnostic Menu Faulty Cable Faulty Main Board	Clean switch and ensure it moves freely. Replace if needed. (AABU8400, AABU8401) The green lights will turn red when the button is pressed.  Check cables from pushbutton to main board. (AACE9402) Refer to Wiring Diagram to ensure correct wire is on correct terminal. Replace main board. (AANEWGEN-RBN)
Meters do not work. Game counter clicks at end of each game. Ticket counter clicks as tickets come out of game.	The 2 wires crimped together may be faulty Pinched, broken, or disconnected wiring Main board faulty.	Inspect crimp to ensure good connection. Check connections from counters to main board. Check continuity on wires. (AACE3320, AACE9406) Replace main board. (AANEWGEN1-RBN)

BALLS NOT RELEASING



Problem	Probable Cause	Remedy
<p>Balls are not being released or are always coming down.</p> <p>Ball gate should move down to down position at power on.</p> <p>If ball gate is operating backward, then check wires as noted above.</p>	<p>Mechanical issue causing ball gate to stick.</p> <p>Check for voltage at Actuator driver board</p> <p>Check for voltage on cable CE9402</p> <p>Check for voltage on cable CE9400</p>	<p>Check for free movement of assembly with actuator not attached.</p> <p>Cable CE9405 should have +12 VDC at all times.</p> <p>Enter Diagnostic Menu - (Down Button lowers bar, Up Button raises bar) Check voltage on CE9402 into actuator driver board: It should be -3 VDC when bar is moving up. It should be +3 VDC when bar is moving down.</p> <p>Enter Diagnostic Menu - (Down Button lowers bar, Up Button raises bar) Check voltage on CE9400 from actuator driver board: Black meter lead on brown wire, red meter lead on blue wire. This cable must be plugged in for reading to be accurate. It should be -12 VDC when bar is moving up and held. It should be +12 VDC when bar is moving down and held</p>

SCORING ISSUES

Information on Scoring:

There are 2 reflective sensors mounted on the back of the hoop.


The game must “see” both of these sensors to score a basket.

It must first see the top sensor, then the bottom sensor. This sequence eliminates the “false score”.

The infrared light from the sensors bounce off the reflective tape in the front of the hoop and creates a beam. The ball will break this beam to score.



A5TA8701 is the reflective tape.



A5BK8400 is the black plastic holding the sensors.

When beam is operating correctly, **both the yellow and green LED's will glow** on right side of sensors.

If only the yellow LED is ON, then the beam is not being reflected back at the sensor.

Check Reflective tape (A5TA8701)

Ensure the housing assembly is pointing straight at reflective tape.

If no LED's are ON, then sensor is not getting power.

Check cables AACE9400 and AACE9412.

Replace sensor. (AACE9400)


POWER SUPPLY DIAGNOSTICS

1.) Verify AC power to front of game. Check power strip in bottom front.
Check for illuminated power switch.

2.) Check AC power connection to power supply.

3.) Ensure Power Supply switch is set to 115V (or 230V)
(Some model power supplies may not have this)


4.) Ensure Power switch is on.



No 12 Volts (Power Supply Fan is not turning), but AC to power supply is OK

This means that either:

- 1.) Power supply is faulty.
- 2.) There is a 12 volt short in cabinet causing power supply to remain off to protect itself.



BILL ACCEPTOR DIAGNOSTICS

Note: There are many different models and brands of Bill Acceptors that are used on redemption games. Your Bill Acceptor may differ from the unit shown.

Standard DBA is MEI # AE2451-U5E Part # A5AC9091

Determine if Bill Acceptor has power:

Turn game ON—The bill acceptor should make noise as stacker cycles and green lights on outside bezel should flash.

If NO power:



Use meter to measure 110 AC voltage at cable going into Bill Acceptor from power strip.

If power is OK:

Clean Bill Acceptor path to make sure there is nothing jamming unit.

Check dipswitch settings on side of acceptor.

Make sure switch # 8 is OFF for Always Enable



ERROR CODES

Count the number of flashes on front bezel of Bill Acceptor and follow chart for repair.

REMOVING MAGAZINE
Push latch on acceptor forward. Slide magazine toward latch and pull away from acceptor.

COUPON SETUP
Coupon recognition requires all switches to be OFF. Press ● on rear of LED cartridge to enter coupon mode. Insert completed coupon. LED will flash 10 times upon successful completion.

DIAGNOSTICS (RED LED LOCATED ON REAR OF LED CARTRIDGE)

# FLASHES	STATUS
1	bill path jammed
2	disabled from system
3	needs cleaning
4	cross channel blocked
5	magazine removed
continuous, slow	unit failure; replace unit
continuous, fast	stacker full

CLEANING THE BILL PATH
Squeeze the metal bar and remove the LED cartridge and magazine for full bill path cleaning.

FOR TECHNICAL SUPPORT CALL: 1-800-345-8172

HOW TO: UPDATE SOFTWARE

Needed for Software Update:

#2 Square bit screwdriver
One USB stick for MiniGen board

Installation Instructions:


Overview – This software upgrade consists of loading the software onto the NewGen Board.

MiniGen Software loading - NOTE: Game power must remain ON for this procedure.

1) Locate the USB stick with the MG designator for MiniGen Board.


2) Access the Minigen main board on bottom front of game. Behind locked door where speaker is located.

3) Insert the USB stick into the main board controller as shown here:



4) To trigger your file to load, press the small pushbutton next to the dipswitches.

NOTE: The file will load quickly; you will notice that the USB stick will flash, audio will reset after about 1 second, and the game will return to normal operating condition.



If you have any questions or need further assistance please contact Bay Tek Games. You may reach our Service Team at 920-822-3951 ext. 1102

OPTIONAL GAME DIVIDERS

****GAME DIVIDERS ARE AN OPTIONAL ADD-ON FEATURE, NOT STANDARD**

TOOLS REQUIRED:

7/16" WRENCH

7/16" RATCHET & SOCKET

TT-27 STAR BIT

#3 PHILLIPS BIT

DRILL

7/32" DRILL BIT (FOUND IN HARDWARE KIT)


LADDER

Set up all games in the bank as instructed in the game manual, leaving a 20" space between. Installing the dividers will be the last steps to complete the bank of games.



Use the provided templates to drill out the necessary holes on the cabinet sides. Tape the templates to the cabinet sides then use the 7/16" drill bit and drill to drill a hole where shown on the template.

There will be a separate template for the bottom black panel and one for the top yellow panel. Repeat drilling for both game cabinets. There will be 6 holes per cabinet - 3 in the black panel & 3 in the yellow panel.




OPTIONAL GAME DIVIDERS

****GAME DIVIDERS ARE AN OPTIONAL ADD-ON FEATURE, NOT STANDARD**

Carefully install the black divider piece between the two cabinets and secure to **ONE CABINET ONLY**, using the 1/4-20 self tappers from the hardware kit.



Place the ladder between the two game cabinets as shown. You may have to enter in through the rear of the cabinets to get the ladder in place.




OPTIONAL GAME DIVIDERS


****GAME DIVIDERS ARE AN OPTIONAL ADD-ON FEATURE, NOT STANDARD**

Carefully lift the yellow net divider piece up the ladder (get assistance if needed!) and set on top of the black divider panel below.

Secure the side of the net divider to the same game cabinet that the lower black divider panel is secured to, using the 1/4-20 self tappers.



Using (2) nylon nuts and (2) flat washers from the hardward kit, secure the bottom of the yellow net divider to the black divider panel.




OPTIONAL GAME DIVIDERS

****GAME DIVIDERS ARE AN OPTIONAL ADD-ON FEATURE, NOT STANDARD**

With assistance, slide the second game cabinet over until it is flush and touching the divider pieces.



Using the same self tappers (6) as earlier, secure the top yellow net divider and the bottom black panel to the second game cabinet.




OPTIONAL GAME DIVIDERS

****GAME DIVIDERS ARE AN OPTIONAL ADD-ON FEATURE, NOT STANDARD**

Secure the table support piece to the front of the black divider panel, using the screws from the hardware kit.



Attach the access hole cover to the front of the black divider panel using the screws from the hardware kit.





OPTIONAL GAME DIVIDERS

****GAME DIVIDERS ARE AN OPTIONAL ADD-ON FEATURE, NOT STANDARD**

Using the TT-27 STAR BIT, remove the self tappers (circled in blue) from the game consoles sides. This is necessary to get the table divider piece in place. Set the self tappers aside for later reinstall.


Install the table support pieces to the front of the game console sides (circled in red) by first removing the self tappers where the support pieces will attach. Reinstall the selftappers once the support pieces are in place.



OPTIONAL GAME DIVIDERS

****GAME DIVIDERS ARE AN OPTIONAL ADD-ON FEATURE, NOT STANDARD**

Carefully place the table piece on top of the support pieces and push down to lock into place.



Using the flat washers and the nylon nuts from the hardware kit, secure the table divider in place as shown.




OPTIONAL GAME DIVIDERS

****GAME DIVIDERS ARE AN OPTIONAL ADD-ON FEATURE, NOT STANDARD**




Reinsert the self tappers to the console sides that you previously removed.




OPTIONAL GAME DIVIDERS

****GAME DIVIDERS ARE AN OPTIONAL ADD-ON FEATURE, NOT STANDARD**


JP



- TABLE HARDWARE
- SECURE TABLE WITH SUPPLIED FLANGE NUTS
 - REAR BRACKET HARDWARE
 - INSTALL BRACKET AS SHOWN WITH SUPPLIED 1/4-20 SCREWS



- TABLE HARDWARE
- SECURE TABLE WITH SUPPLIED FLANGE NUTS
- (2X) FRONT BRACKET HARDWARE
- REMOVE TORX SCREWS
 - INSTALL BRACKET AS SHOWN
 - REINSTALL TORX SCREWS



- PANEL HARDWARE
- SECURE TOP AND BOTTOM PANELS TOGETHER WITH SUPPLIED FLANGE NUTS (2X)
 - PANELS WILL NEED TO BE SECURED TO GAME USING SELF TAPPING HARDWARE NOT SUPPLIED
 - ENSURE BOTH GAMES ARE IN LINE WITH EACH OTHER DURING SET UP
 - MAINTAIN A 18-1/16" TO 18-1/8" GAP BETWEEN GAMES DURING SET UP

PARTS LIST

Part Number	Description	Part Number	Description
A5BA8703	Basketballs - Regulation Size	AACE8811	Speaker Assembly
A5CB2050	Cash Box	AAPB2700	Push Button Assembly
AASW200	Low Ticket Switch	AACO9400	Rope Light Assembly
A5ME9406	18" Rim (Rim Only)	AAKIT-SHOT	Game Linking Kit (Link up to 8 Games)
A5NE8402	Rim Net	A5TD1	Ticket Dispenser
A5FI9010	Inline Filter	AAPS1013-HS	Power Supply
A5TA8701	Reflective Tape	AAAC9400	Actuator
AABK1013	Menu Push Button Bracket With Decal	A5DE9400	Display Board Acrylic
A5NE9400	Top Net (Top of Game, 3 Per Game)	A5DE9401	Backboard Acrylic
A5NE9401	Side Nets (Side of Game, 3 Per Side)	A5DE9403	Left Side Panel Decal
A5LA8400	Wood Grain Laminate Floor	A5DE9404	Right Side Panel Decal
A5FO8400	Foam Flooring under Laminate	A5DE9405	Top Back Wall Crowd Decal
AABU8400	"Solo" Button	A5DE9406	Middle Back Wall Crowd Decal
AABU8401	"Group Up" Button	A5DE9407	Bottom Back Wall Crowd Decal
A5LK5002	Lock 7/8" H95 Key Code	A5DE9408	Group Button Decal
A5PL9097	Blanking Plate (Replaces Bill Acceptor)	A5DE9409	Solo Button Decal
A5PL9998	Blanking Plate, No Holes (Coin Door)	A5DE9410	Front Cabinet Decal
A5BK8400	Swivel Sensor Bracket	AAWO9400	Black Melamine Console Ramp
A5ME2035	Metal Ticket Tray	AAWO9401	Black Melamine Ramp Floor
A5ME8321	Metal Cash Box Holder (1 of 3)	AAWO9402	Rear Lower Wall Wood (No Decal A5DE9407)
A5ME8322	Metal Cash Box Holder (2 of 3)	AAWO9406	Hoop Backboard Wood
A5ME8323	Metal Cash Box Holder (3 of 3)	AAWO9408	Rear Upper Wall Wood (No Decal A5DE9405)
A5CORD29	25' SJT Cord	AAWO9409	Rear Middle Wall Wood (No Decal A5DE9406)
AACBL4A-DOORA	Door Cable	WARR0021-HS	Light Guard Console Poly
AACE3320	Counter Assembly	WARR0023-HSHOT	Side Window Display
AACE9400	Display Signal Power Cable	AAKIT-HOT-DECAL	Crowd Graphic Cover W Plexi Guard
AACE9401	Spot Light Power Cable	AALD1052	LED Display Board Conversion
AACE9402	Coin Door, Low Ticket & Button Cable	AASE9400	Hoop Sensor
AACE9403	Ticket Dispenser Cable	AACB6401	Booster Board for Display
AACE9404	New Gen1 to Speaker Cable	AACB3904-2	Ribbon Splitter Board
AACE9405	Power Control Cable	AACB3906	Actuator Driver Board
AACE9406	Menu Buttons and Counter Cable	AANEWGEN1-RBN	New Gen1 Main Board
AACE9407	Outlet Strip Assembly		
AACE9408	DBA Cable		
AACE9409	Left Door to Ground Stud Cable		
AACE9410	Right Door to Ground Stud Cable		
AACE9411	Ground Pusher to Ground Stud Cable		
AACE9412	Hoop Sensor Cable		
AACE9413	New Gen1 Power Cable		
AACE9414	Back Rope Light Cable		
AACE9415	Display Ribbon Jumper Cable		
AACE9417	New Gen1 to Power Ribbon Cable		
AACE9418	Display Jumper Cable		


PARTS PICTUES




A5BA8703



A5CB2050



AASW200



A5ME9406




A5NE8402




A5FI9010



A5TA8701



AABK1013



A5NE9400



A5NE9401



AABU8400



AABU8401



A5LK5002



A5PL9097



A5PL9998




A5ME2035



A5ME8321



A5ME8322




A5ME8323



A5CORD29



AACBL4A-DOOR



AACE3320




AACE9400



AACE9401




AACE9402




AACE9403



AACE9404



AACE9405




AACE9406




AACE9407




AACE9408




AACE9409




AACE9410




AACE9411




AACE9412




AACE9413



AACE9414



AACE9415



AACE9417



AACE9418




AACE9419



AACE9420



AACE9421



AACE9734



A5CE9736



AACE8811

TECHNICAL SUPPORT

Excellent customer service is very important to Bay Tek Games!

We know that keeping your games in great operating condition is important to your business. When you need us, we are here to help. You can call us for free technical assistance, and you can count on us to have parts on-hand to support your game. We offer options that fit your needs.

Electronics / Circuit Boards - Repair Options

Repair & Return – If you have Circuit Board issues with your Bay Tek game, you can send the board to us and we'll repair it right away. Most items sent to us are repaired and returned to you within two days. This option is your best value as we offer this fast turn-around service at the most reasonable price.

Advance Replacement – If you have Circuit Board issues with your Bay Tek game, but you don't have time to send in your board in for repair, give us a call and ask for an Advance Replacement. We'll send you a replacement board that same day (pending availability). When you get your new board, just repackage the defective board in the same box and send it back to us. We make it easy by including a UPS Return Shipping label for you to put on the box (not available for international shipments). This is your best option when you need to get your game up and running as quickly as possible!

Spare Parts – Take matters into your own hands and purchase new spare Circuit Boards for your Bay Tek games. Many of our games share the same main-board electronics. This means you can buy one set of spare electronics to support many of your Bay Tek games. Spare boards allow you to get your game up and running the quickest and provide you a valuable troubleshooting option. Call our technicians to get recommendations for what you should keep on hand for spare parts!

Technical Support:

"You" are the best tool for troubleshooting! Your abilities to understand the game and your skills to repair the game are invaluable to us! If you need help, you know you can call us. It's not easy to diagnose a game remotely by phone, but our technicians do a great job. They'll need your help to perform some troubleshooting steps and convey to them exactly what's happening with your game.

Returns, Credits, & Fees:

NOTICE! ALL ITEMS being sent to Bay Tek Entertainment for repair or return, etc. require prior Return

Authorization! Bay Tek Entertainment will provide a Product Return Form with an authorizing Ticket Number for each item to be returned. Please be certain to include this document with all shipments!

Late Fees and Non-Return Fees - Advance Replacement and Warranty Replacement items require the defective items to be returned by Bay Tek Entertainment promptly to avoid Late Fees. We expect items to be returned with 10 working days. Late fees are invoiced monthly. Late fees are non-refundable under any circumstance! Any item not returned within 90 days will be invoiced in full as a replacement part.

Bench Fees - Bench fees will apply for each electronic item returned to Bay Tek Entertainment (this includes unused Advance Replacement items). This charge covers our cost to inspect, evaluate and retest each item. Please note that returned items that do not pass our tests will be charged accordingly as replacement items or advance replacements.

Restocking Fees - Unused items returned for credit will be credited minus a restocking fee. Items must be returned within 30 days of purchase in order to qualify for any credit amount. No shipping charges will be credited.

WARRANTY

Bay Tek Entertainment warrants to the original purchaser that all game components will be free of defects in workmanship and materials for a period of 6 months from the date of purchase. If you fill out the registration card in the cashbox of the game, Bay Tek will add another 3 months to your warranty, free of charge.

Bay Tek Entertainment will, without charge, repair or replace defective component parts upon notification to the parts/service department while the game is under warranty.

Warranty replacement parts will be shipped immediately, via ground service, along with a Product Return Form for the return of defective parts.

Defective parts must be shipped back to Bay Tek Entertainment unless otherwise instructed. Items not returned to Bay Tek Entertainment will be invoiced as replacement parts.

This warranty does not apply in the event of any misuse or abuse to the product, or as a result of any unauthorized repairs or alterations. The warranty does not apply if any serial number decal is altered, defaced, or removed from its original position.

 **ATTENTION** 

In order to maintain the safety & compliance certifications of this game, **ONLY** approved parts may be used. For approved replacement parts, refer to the parts list in this manual.

Should you need your game serviced, determine the serial number from the decal placed on the front of this manual, or locate it on the back of the game. Then contact our Service Department at: 920.822.3951 or e-mail: service@baytekent.com

NON-WARRANTY

Options and estimated charges will be provided to you for your approval.

Please remember that any items being sent to Bay Tek Entertainment must include prior return authorization from our Parts & Service Department.

This approval will include a Product Return Form which is required to be included with any incoming shipments. Repaired parts will be shipped back using the same method in which they were received.

Repairs are warranted for 30 days from the date of return shipment.