

Insulated Panels
Poland, Lithuania, Latvia, Estonia, Ukraine

Kingspan

DSH1

Swing doors (hinged)

Swing doors (hinged, single leaf) - traffic doors.





Technical information:

Temperature range:

- Swing doors: 0°C to above + 16°C

Door leaf:

- 40 mm thick
- Galvanized steel covered with 25 µm PES coating in R9002/R9010; protection foil
- Other material can be used, e.g. INOX stainless steel, Foodsafe chemically neutral coating 150 µm thick for interior and food contact applications, etc.
- Foamed-in-place polyurethane insulation of 42 (+/- 2) kg/m³ density
- Equipped with a peripheral gasket that seals the contact between the door leaf and the frame
- The bottom brush seal that seals the contact between the door leaf and the floor
- Plexiglass windows with dimensions 300x700 mm
- Plastic buffers



Door frame:

- Fitted onto the opening
- Inox steel
- Not insulated
- One-sided for traditional assembly

Hardware:


- Provided by INGRADO.

Standard dimensions range:


- min: 700x1800 mm,
- max: 1200x2500 mm
- Dimensions other than standard.




Drawings of installation:



Assembly in to panel



Assembly in to wall



Installation guide:

1. Unpack doors.
2. Read a product description and compare it with your order and goods that have arrived to you (width, height, opening direction).
3. Check dimensions of an opening in a wall with the ones recommended by a producer.
4. Clean and smooth edges and surfaces of the opening.
5. Check the floor level at the area of a leaf revolution.
6. Take the door leaf down a frame and remove a technological beam.
7. Put the frame temporarily in the chosen opening in the wall and immobilize it.
8. Correct the initial arrangement of the frame in the opening and immobilize it with quick installation handles.
9. Indicate and make installation holes for screws (installation to panels) or anchors (installation to brick wall).
10. Install flashings in case of installation to panel.
11. Put the frame in the prepared place and immobilize it with quick installation handles.
12. Check the horizontal and vertical level of the frame and regulate it if necessary.
13. Check how the leaf closes and opens in the frame - depending on the situation, regulate it.
14. Tighten screws to install the arms of the frame.
15. Fill in a gap between the frame and the wall (the frame and a panel) with silicone.
16. Cover installation holes.
17. Remove protective foil from the leaf surface directly after the installation.

Maintenance

Recommendations:

- At least twice a year you should smear lubricant on all hinges and a lock.
- At least twice a year you should preserve gasket with a substance for sealant preservation.
- You should fill in a loss of lacquer or zinc layer (which has been caused by scratches) to prevent the product from corrosion. Losses should be filled in with commonly-used anticorrosion paints.
- For door should not act directly to weather conditions (rain, snow, sun) and should be protected at least a roof that protects for mention conditions.

Transport and storage of doors

- You should exercise extreme caution while door transport and storage.
- Loading room should be clean and no sharp elements should stick out of the floor and walls to prevent doors from damage.
- Doors for transport (storage) should be laid vertically (separately) or horizontally – maximum 5 layers separated with a protective separator (standard-sized doors are packed in a carton box). In cases of big-sized doors, transport and storage should be arranged on a special rack.
- In the case of large doors, transport and storage should take place on special stands..
- During loading, the doors should be set so that the plane of the wings is parallel to the longitudinal axis of the vehicle.
- Doors that have been loaded on a truck should be belted to the vehicle in such a way that stability is ensured and goods are prevented from movement and damages during transport.
- Doors packed on a pallet should be stored and transported in such a way, with the difference that the pallet with the door can be moved and loaded with a forklift.
- Storage place should be dry and airy; apart from this it should shelter doors from rain, snow and sunlight.

Poland:

Kingspan Sp. z o.o.
ul. Przemysłowa 20
27-300 Lipsko
tel.: +48 48 378 31 00
fax: +48 48 378 13 30
www.kingspan.pl

Estonia:

Kingspan Eesti
Tel (+371) 28 393 333
info@kingspan.ee
www.kingspan.ee

Latvia:

Kingspan Latvia
Kronvalda bulv. 3-1
LV-1010 Riga
Tel: +371 28393 333
info@kingspan.lv
www.kingspan.lv

Lithuania:

UAB Kingspan
Neries kr. 16
LT-48402, Kaunas
Tel: +370 66 565 862
info@kingspan.lt
www.kingspan.lt

Ukraine:

ТОВ «Кінгспан-Україна»
7Б Наукова, офіс 113В
79060 м. Львів
+38 067 538 8930
email: info@kingspan.ua
www.kingspan.ua

Information about the product offer in others countries can be obtained from your local sales representative or on the website www.kingspan.com

Although Kingspan makes every effort to provide information contained in this publication were as accurate as possible, correct and complete, please note that its content should not be the basis of the procedure in any particular case. Any advice, opinions, information or other content is published solely based on the principle that neither the company, its employees or representatives, or people who contributed to the uprising of this publication, do not assume any liability for its content or any damage caused in connection with this content.

Issue: 05/08/2025 (v3)

To ensure you are viewing the most recent and accurate product information, please scan the QR code:

