

Adhesive matrix based on parquet formats

Glue scale	Adhesive MS 25	Adhesive MS 35	Adhesive MS 70	F5*	Adhesive Trowel type
Unicopark			●		B12–B13
Silverline Edition Villapark Villapark 2194 Studiopark	●	●	●		B8–B10
Spinpark			●		B8–B10
Casapark Click	●	●	●		B12–B13
Formpark 780 & 520 Formpark Mini 570 & 380 Formpark Quadrato Formpark Rombico		●	●		B8–B10
Trendpark 1390	●	●	●	●	B6–B8–B10
Cleverpark 1250	●	●	●		B8–B10
Cleverpark 900	● ₂	●	●		B8–B10
Vectorpark	● ₂	●	●	● ₂	B8–B10
Unopark Solopark Monopark	● ₂	●	●	● ₂	B6–B8–B10
Multipark 10	●	●	●	●	B8–B10
Multipark 9.5	●	●	●		B8–B10
Solid parquet On-edge	● ₁	● ₁	● ₁	●	B6–B8–B10
Prepark Prepark Comfort	●	●	●	●	B6–B8–B10
Triopark	●	●	●		B12–B13

Note

- * when applying F5 on calcium sulphate flowing screed, apply first Bona D515. Please follow the special instructions for the F5 dispersion adhesive provided in our technical data sheet.
- ¹ If the parquet surface is lacquered later, Bona lacquer must be used for that purpose, in order to prevent any staining due to chemical reactions. For oiled surfaces, choose the oil you prefer.
- ² For complex laying patterns, we primarily recommend the use of MS 35 or MS 70 due to their shorter open time.

General Information

- this table is applicable for examined, suitable subfloors for parquet such as cement-, calcium sulphate- and calcium sulphate flowing screed, chipboards and fibreboards.
- all types of glue listed in this overview are suitable for underfloor heating.
- for any further information please address to your contact person.