



STEP 1:
 LOCATE THE BLACK PLASTIC BATTERY PACK AND 4 'D' SIZED BATTERIES (NOT INCLUDED). USING SCREWDRIVER, OPEN THE BATTERY PACK BY REMOVING THE TWO SCREWS LOCATED ON THE COVER OF THE PACK. SEE IMAGE AT LEFT. INSTALL BATTERIES INTO BATTERY PACK.

USE VELCRO DOTS TO FIX PACK INTO OPEN SLOT IN THE FIXTURE NEXT TO THE PUMP.

DO NOT ATTACH WIRES TO PUMP AT THIS POINT.

STEP 2:
 PLACE 1 GALLON JUG OF HAND SANITIZER SERUM ONTO BASE OF FIXTURE AS SHOWN AT LEFT. REMOVE AND DISCARD THE CAP AND SAFETY SEAL ON THE BOTTLE.

REPLACE WITH THE PROVIDED CAP WITH HOLE. FEED THE LONG TUBE THAT COMES FROM THE PUMP, THROUGH THE HOLE IN THE NEW CAP. FEED HOSE INTO BOTTLE UNTIL HOSE HITS THE BOTTOM FLOOR OF THE BOTTLE.

STEP 3:
 PLUG THE POWER LEAD FROM THE BATTERY PACK INTO THE SOCKET ON THE PUMP HOUSING.

SEPT 4:
 PRIME PUMP BY RUNNING HANDS BY ELECTRIC EYE/NOZZLE A FEW TIMES UNTIL FLUID IS DISPENSED IN A CONSISTENT MANNER.

THIS MAY ALSO NEED TO BE DONE IF THE UNIT SITS FOR 24 HOURS WITHOUT ACTIVATION

REV:

DRAWN BY: KS

DRAWN DATE: 1/21/2021



B&N INDUSTRIES
 650.593.4127
 WWW.BNIND.COM