


RF-150



---

RF—150 USB RFID reader

---



**Combine with our Time Clocks**

Works smoothly with all our Time Clocks. Whether you have the TM— 616 or TM—838 SC.


**Portable.**  
**Compact.**  
Fits easily on your desk,  
register an employee in  
minutes at your PC.

TimeMoto RF—150 portable USB RFID reader enables you to register a new RFID Badge or a new key fob right at your PC, instead of at your Time Clock. Just open your TimeMoto PC / PC Plus Software, register the new badge and assign it to the desired employee—all without leaving your desk. Within minutes, your employee can use their new RFID Badge or Key fob to punch in and out at any Time Clock within your network, even at remote locations.

Activate. Wherever it's convenient.

TimeMoto RF—150

- USB reader for RFID Badges
- Reads 125KHz RFID Badges and key fobs
- Activate RFID Badges / key fobs directly at your PC
- USB connection cable included
- Small footprint, fits on any desk
- Dimensions: 6.4 x 11.5 x 1.7 cm



Combine with TimeMoto Cloud

All Time Clocks include the Free Plan and a 30-day Plus Plan trial.  
Experience every feature before choosing the plan that best fits your needs.

# RF—150

Brand	TimeMoto
Model	RF—150
Article	125-0605
EAN	8717496336460
Technical specifications	<p>Reads 125KHz RFID Badges and key fobs</p> <p>Activate RFID Badges / key fobs directly at your PC</p> <p>USB connection cable included</p> <p>Small footprint, fits on any desk</p> <p>Dimensions: 6.4 x 11.5 x 1.7 cm</p> <p>Weight: 117 gr</p> <p>PC requirements: Windows 7, Windows 8, Windows 10</p>
Package contents	USB reader for RFID Badges
Compatibility	Only compatible with PC / PC Plus Software, not suitable for TimeMoto Cloud