




RControl Admin App Overview v2.0

LOGIN

Get the *RControl Admin* app from the App Store or Google Play.


Once you've downloaded and installed *RControl Admin*, use the dealer credentials provided by your Central Station.

www.rcontrol.com RCONTROL 401-233-4000

 **RControl**
A D M I N

Welcome, please Sign in.

Username:

Password: 


[Forgot your password?](#)

SIGN IN

CHECKING THE SIGNAL LEVEL

The main screen shows important general information for the device such as:


- Signal Level
- Serial number
- Account number



SETTINGS MENU


Go to "Settings" to access:

- Device Details
- CMS Settings
- End Users information




CHANGING THE NAME OF THE DEVICE

To change the device name, go to "Device Details".




Type the device name and press "Save Settings".



OVERWRITING AN ACCOUNT NUMBER CONFIGURED ON THE PANEL


Go to "CMS Settings".



Uncheck "From Panel" to enter the new account number.

Overwrite the account number configured on the panel.


Press "Save Settings" when you are done.



MANAGING THE END USERS


It is recommended that end user account management is done directly from the RControl Mobile App (e.g. update account credentials, adding new device, adding new users and etc.).

Go to "End Users" to manage End User Accounts.



Select the user that you want to modify.

Add new with the "plus" symbol top right



MANAGING THE END USERS

It is recommended that end user account management is done directly from the RControl Mobile App (e.g. update account credentials, adding new device, adding new users and etc.).

Fill in the desired fields and press "Save Settings" when you are done.

You can change the password to an existing user by typing it here and then saving the settings.

Users

SAVE SETTINGS

Name:

Password:

Confirm password:

Login name:

Language:

Default

English

Email address:

* This email will only be used for password recovery.

Enable/Disable the selected user.

Users

Language:

Default

English

Email address:

* This email will only be used for password recovery.

Master user

Device diagnostics

Remote Permission

Bypass Permission

Remote Control

Enabled

CHECKING THE EVENTS OF THE DEVICE

The "Events" tab displays the event log related to the selected device.

