


Device Comparison Chart



Footnotes:

- ¹ For a list of all compatible panels please visit **support.m2mservices.com**
- ² Additional MN01-RNGR device is needed to use UDL with MiNi-LTE-M-AV.
- ³ MiNi-LTE-M-AV comes with a Hardware-as-a-Service business model. Learn more at www.m2mservices.com




Dealer Resources

M2M Dealer portal - https://www.m2mdealers.com

- Assign devices to a central monitoring station
- Select a billing option
- Change central monitoring stations
- ✓ Suspend and reactivate devices

Learn how to register from the Quick Installation Manual, provided with each device.





M2M Support site - https://support.m2mservices.com/

- Device cutsheets and installation manuals
- Panel programming guidelines
- ✓ Interactive App guidelines
- Support contact form

M2M Support contacts:

support@m2mservices.com

800-403-7029 (6:00 AM – 6:00 PM EST, business days, Monday – Friday)

