



15L door mount swing bin

Things you need to know

- Always read the full instructions prior to installation.
- Consider possible obstructions to your parts & accessories, like hinges inside the cabinet or adjacent cabinet doors and handles, prior to installation.
- Make sure you leave plumbing and electrical work to qualified trades people. Never try this yourself.
- Make sure you always use safety gear like a mask, ear muffs and glasses when using tools.

installation guide

- This waste bin is designed to be installed in cabinets with either left or right hand opening set up.
- Tip: After marking out the pre-drill holes as per the instructions, take the part that is to be installed and align the appropriate holes with the markings to ensure they match up prior to pre-drilling the holes.
- If you have any questions, contact us on: Australia: 1800 666 078 Monday to Friday between 8:00am and 6:00pm AEST, New Zealand: 0800 522 663 Monday to Friday between 8:00am and 5:00pm NZST or email: info@kaboodlegroup.com.au.

Hardware included



















Tools you will need

To put your kaboodle kitchen waste bins together you will need the following tools.















Tape measure

Screw Pencil driver

Safety gear

Adjustable sauare

Clamps (optional)









В







G





lid bracket outer b

outer bucket door bracket


rotating axi

mm screws 20mn

pre-drilling for brackets

1.

right open shown




Use the template provided to mark out and pre-drill the holes for all three brackets. The placement of the template depends on which way your door opens.

15L door mount swing bin

assembling lid and outer bucket

2.




Fit the lid bracket (B) to the lid (A) using two of the screws (H) provided as pictured above. Ensure you have the correct orientation depending on which way your door opens. Fit the rotating axis (G) to the outer bucket (C), again ensuring you have the correct orientation.

installing brackets

3.

right open shown




Using 6 of the screws (I) provided, fit the lid bracket (B), the outer bucket bracket (E) and door bracket (F) to the cabinet and door as pictured above.

installing outer bucket

4.

right open shown



Fit the top of the outer bucket into the lid bracket ensuring that the bottom of the outer bucket fits over the pin on the door bracket, as pictured above.





15L door mount swing bin

installing bin

6.


right open shown




connecting to door bracket

5.

right open shown



Swing the outer bucket towards the door and gently lift onto the door bracket. Once in place the bin should open and close automatically with the door.



Place the bucket (D) into the outer bucket to complete installation.

Caring for your kaboodle cabinets

Looking after your cabinets is really easy and with the right care and maintenance they will last you for many years. Just follow these simple steps and if you need any more information you can contact us: Australia: 1800 666 078 Monday to Friday between 8:00am and 6:00pm AEST. New Zealand: 0800 522 663 Monday to Friday between 8:00am and 5:00pm NZST or email: info@kaboodlegroup.com.au.

Caring for your kaboodle parts and accessories: Looking after your parts and accessories is really easy and with the right care and maintenance they will last you for many years. Just follow these simple steps. Hinges, runners and other parts and accessories should be kept dry at all times. To keep the mechanisms performing at their best, regularly wipe them with a dry cloth removing any dust and grime that may build up. In case of spills, clean immediately with a dry cloth. Do not use harsh abrasives.

We offer a dedicated customer service line for advice or any questions you may have on kaboodle products. Call customer service on:

Australia: **1800 666 078** Monday to Friday between 8.00am and 6.00pm AEST

New Zealand: **0800 522 663** Monday to Friday between 8.00am and 5.00pm NZST or email: **info@kaboodlegroup.com.au**

