


# attaching push to open mechanism and catch

hardware key











# Identifying the location of the push to open mechanism


depending on the type of cabinet, the location of the Push to Open mechanism will vary.

## base cabinets



### wall cabinets





### for installation in single door cabinets




2.




pre-drill holes and use the 22mm screws to attach the mechanism.




### for installation in double door cabinets




2.



pre-drill holes and use the 22mm screws to attach the mechanism.








### removing hinge plate


1.


remove the hinge from the hinge plate by pushing on the release tab.



### attaching hinge plate to cabinet







### Caring for your Kaboodle parts and accessories

Looking after your parts and accessories is really easy and with the right care and maintenance they will last you for many years. Just follow these simple step. Hinges, runners and other parts and accessories should be kept dry at all times.

To keep the mechanisms performing at their best, regularly wipe them with a dry cloth removing any dust and grime that may build up. We offer a dedicated customer service line for advice or any questions you may have on Kaboodle products.

Call customer service on **1800 666 078** Monday to Friday between 8:00am and 6:00pm AEST or email <code>info@kaboodlegroup.com.au</code>.