




Art Frame®


Manual

MANUAL


What's in the box?



Frame parts
4 pcs



Corner connectors
4 pcs



Wall brackets
4 pcs



Swappable Print
1 pc



Allen key
1 pc




Also needed (not included)



Screws
8 pcs



Wall plugs
8 pcs



Drill
1 pc




Spirit level
1 pc

IXXI


STEP 1

Lay the Frame out on the floor




STEP 2

Slide the Corner Connectors into the Frame parts and tighten them




STEP 3



Screw the Wall Brackets to the wall



1



2



1

Mount two Wall Brackets to hang the top of the frame on.




Optional: Mount the two remaining Wall Brackets at the bottom of the frame for extra stability.

2

Place the Frame on the two Wall Brackets.

STEP 4




Level the Frame





Turn the screw from below with the Allen Key to level the Frame.

STEP 5

Press the Rubber Edge into the Frame




Tip: Start at the corners. This makes it easier to fit the Fabric.
Position the Fabric so that no white Rubber Edge is visible from the front.



Tip: Once the Frame is level, take it down again and lay it down carefully to stretch the Fabric into it.

STEP 6

Hang your Frame on the wall



Done. It's up!

Now sit back and enjoy your new
IXXI Art Frame®.

IXXI