




Quick start guide

Turn on		➔ Set the main switch to "EIN" The "ON" button on the hand switch flashes ➔ Press the "ON" button on the hand switch Control is active
Manual Mode		➔ Press the "MANUAL" button Button "MANUAL" flashes, Manual mode is active ➔ Press the Up "↑" button Fork moves upwards as long as the button is pressed ➔ Press the Down "↓" button Fork moves downwards as long as the button is pressed
Automatic Mode		➔ Press the "AUTO" button Buttons „↑“, „↓“ und „AUTO“ flashes, Select mode ➔ Press the Up "↑" button Semi-automatic - destacking only ➔ Press the Down "↓" button Semi-automatic - stacking only ➔ Press the "AUTO" button Fully automatic - stacking and destacking 
Set-down Mode While an automatic mode is active		➔ Press "ON" + "AUTO" simultaneously Set-down mode - automatic drive down to the safety zone of 120 mm



Observe the safety notes in the operating instructions!