



VS4

Bedienung • Operation • Opération • Operazione




Demontage • Disassembly • Démontage • Smontaggio


Falzmontage • Top fixing • Montage en feuillure • Montaggio a libro



Winkelmontage • Face fixing • Montage en angle • Montaggio ad angolo



Option • Opzione




Montageanleitung • Assembly instruction Instructions de montage • Istruzioni di montaggio

DE • EN • FR • IT
















VS4, VS4 S

Wichtig! Bitte mit den Produkthinweisen aufbewahren! • Important! Please keep together with product information!
Important! A conserver avec les instructions relatives au produit! • Importante! Si prega di attenersi alle istruzioni del prodotto!





Falzmontage
Top fixing
Montage en feuillure
Montaggio a libro



Winkelmontage
Face fixing
Montage en angle
Montaggio ad angolo

