

### 3. Perfecta 900 equipment supplied with internal coolant supplying

<p>Knee control unit</p> <p>Control unit:</p> <ul style="list-style-type: none"> <li>○ REF 05223900 230 V</li> <li>○ REF 05224000 115 V</li> </ul> <ul style="list-style-type: none"> <li>○ Operating controls LA-9D REF 05243400</li> <li>○ Fitting for blow out function REF 05148800</li> <li>○ Holding plate REF 01170500</li> <li>○ Tapping screws REF 00952200</li> </ul>	<p>Table control unit</p> <p>Control unit:</p> <ul style="list-style-type: none"> <li>○ REF 05223500 230 V</li> <li>○ REF 05223600 115 V</li> </ul> <ul style="list-style-type: none"> <li>○ Operating controls LA-9D REF 05243400</li> <li>○ Foot-operated starter L-NV REF 05038100</li> <li>○ Foot stand for control unit REF 04820800</li> </ul>	<p>Knee-, Table control unit</p> <ul style="list-style-type: none"> <li>○ Motor cable 1.8 m for LA-9 REF 05117800</li> <li>○ Hose for air supply REF 05250400</li> <li>○ Motor handpiece LA-9 (without motor cable) REF 05015900</li> <li>○ Handpiece holder REF 03211500</li> </ul> <p>optional:</p> <ul style="list-style-type: none"> <li>○ <i>Motor cable 1.8 m for LA-66 REF 05116500</i></li> <li>○ <i>Motor handpiece LA-66 (without motor cable) REF 05201200</i> <ul style="list-style-type: none"> <li>○ <i>Chuck key REF 01125900</i></li> <li>○ <i>Spanner REF 03202800</i></li> <li>○ <i>W&amp;H Service oil REF 03304500</i></li> <li>○ <i>Cleaning brush REF 00669400</i></li> </ul> </li> <li>○ Mains cable REF 01343700 (Europa)</li> </ul> <p>alternativ:</p> <ul style="list-style-type: none"> <li>○ Mains cable REF 01343900 (USA, CAN, J) / REF 03212700 (UK, IRL) / REF 02909300 (AUS, NZ) / REF 04280600 (CH)</li> </ul>
---	--	--

## Perfecta 900 equipment supplied with external coolant supplying

<p>Knee control unit</p> <p>Control unit:</p> <ul style="list-style-type: none"> <li><input type="radio"/> REF 05333600 230 V</li> <li><input type="radio"/> REF 04542400 115 V</li> </ul> <ul style="list-style-type: none"> <li><input type="radio"/> Operating controls LA-9D REF 05243400</li> <li><input type="radio"/> Fitting for blow out function REF 05148800</li> <li><input type="radio"/> Holding plate REF 01170500</li> <li><input type="radio"/> Tapping screws REF 00952200</li> </ul>	<p>Table control unit</p> <p>Control unit:</p> <ul style="list-style-type: none"> <li><input type="radio"/> REF 05334200 230 V</li> <li><input type="radio"/> REF 05334300 115 V</li> </ul> <ul style="list-style-type: none"> <li><input type="radio"/> Operating controls LA-9D REF 05243400</li> <li><input type="radio"/> Foot-operated starter L-NV REF 05038100</li> </ul>	<p>Knee-, Table control unit</p> <ul style="list-style-type: none"> <li><input type="radio"/> Motor cable 1.8 m for LA-9 REF 05117800</li> <li><input type="radio"/> Hose for air supply REF 05250400</li> <li><input type="radio"/> Hose for coolant supply REF 05075600</li> </ul> <ul style="list-style-type: none"> <li><input type="radio"/> Motor handpiece LA-9 (without motor cable) REF 05015900</li> <li><input type="radio"/> Handpiece holder REF 03211500</li> </ul> <p>optional:</p> <ul style="list-style-type: none"> <li><input type="radio"/> <i>Motor cable 1.8 m for LA-66 REF 05116500</i></li> <li><input type="radio"/> <i>Motor handpiece LA-66 (without motor cable) REF 05201200</i> <ul style="list-style-type: none"> <li><input type="radio"/> <i>Chuck key REF 01125900</i></li> <li><input type="radio"/> <i>Spanner REF 03202800</i></li> <li><input type="radio"/> <i>W&amp;H Service oil REF 03304500</i></li> <li><input type="radio"/> <i>Cleaning brush REF 00669400</i></li> </ul> </li> <li><input type="radio"/> Mains cable REF 01343700 (Europa)</li> </ul> <p>alternativ:</p> <ul style="list-style-type: none"> <li><input type="radio"/> Mains cable REF 01343900 (USA, CAN, J) / REF 03212700 (UK, IRL) / REF 02909300 (AUS, NZ) / REF 04280600 (CH)</li> </ul>
---	--	---