


User Manual


Wireless Active Noise Cancelling Headphones

BTHS-ANC032










Overview	1
Basic Operations	1
Connect to a Bluetooth device.....	1
Reconnect to Bluetooth device.....	2
Active Noise Cancellation.....	2
Using as a wired headphone.....	2
Status of LED Indicators	3
Charging	3
Troubleshooting	4


Overview



Basic Operations

Function	Operation
General	
Power ON / OFF	Hold  for about 3s
Enter Pairing Mode	From off status, hold  for 5s till the LED indicator blinks RED and BLUE alternately
Clear Paired history	After power on, hold BOTH + & - for 5 seconds till LED blinks RED & BLUE twice then release the buttons.
Music control	
Play / Pause music	Press  once
Volume up/down	Short press + or -
Next/ Previous track	Long press + or -
Call control	
Answer / end a call	Press  once
Reject a call	Hold  for 1s when receiving an incoming call
Voice dial(Phone feature)	Hold  1s
Redial the last called phone	Press  twice
Activate / Deactivate Microphone mute	In calling status, press BOTH + or - once to activate / deactivate microphone mute

Connect to a Bluetooth device

1. **Set headset into PAIRING MODE** – From off state, hold  for 5s till the LED indicator flashes RED & BLUE alternately.
2. On your device, turn on the Bluetooth feature and select “Avantree ANC032” to connect. If you are using a Bluetooth transmitter, please set your transmitter to PAIRING MODE (follow its user manual).

3. Once connected, the LED will flash BLUE once every 10 seconds.



Reconnect to Bluetooth device


Normally, when powered on, the headphones try to reconnect with the most recently connected device. For other devices, please select "Avantree ANC032" to connect manually.

Note:

- The devices must be in range and powered on,
- The reconnection function depends on the different make/model of devices. Some TVs DO NOT support automatic reconnection to headphones.

Active Noise Cancellation


Press **[ANC]** button once to activate the ANC function, the LED will remain GREEN. Press **[ANC]** again to deactivate ANC function.



Note: If the headphone battery is depleted, you cannot use the ANC function.

Using as a wired headphone

Use the supplied 3.5mm audio cable to connect a non-Bluetooth device, or if the headphones battery is depleted.




Status of LED Indicators

Indicator Light	Headphones Status
Red LED blinking	Low battery
Red solid	Charging
Green solid	ANC Activate
Blue and red alternately	Ready to pair
Blue flash one time every 10 seconds	Connected
Blue flash two time every 10 seconds	NOT connected

Charging

If you hear a beep sound once a minute, you should recharge your headphones. Please plug it into a USB wall charger (DC 5V / 0.5-2A) or a powered computer USB port via attached micro USB cable. Normally it will take 2.5 hours to fully charged. The LED will remain red when charging and will turn off when charging is complete.



Troubleshooting

- **No sound with PC?**

- Set Avantree ANC032 as the default device or output device on the PC.
- When using ANC032 to make VOIP calls through apps, please set ANC032 Hands-Free as Microphone and Speakers device.

- **No sound with Bluetooth transmitter to watching TV?**

- Check to ensure audio source is functioning properly
 - AUX & RCA output on TV – test with wired headphones
 - OPT output on TV – Set audio format to “PCM/LPCM” or turn off Dolby/DTS
- Change your TV audio out setting to External speakers /Headset.
- Ensure Bluetooth transmitter and headphones are connected properly.

- **Headphones do not pair with Bluetooth device**

- Ensure ANC032 is in Pairing mode – LED will flash BLUE and RED alternately.
- For Bluetooth transmitter, ensure the transmitter is in Pairing mode – refer to its user manual.
- For Smart phone, tablet and PC
 - Turn the Bluetooth off and then on again.
 - Delete “Avantree ANC032 headphones” from your devices Bluetooth list and then try to pair again
- Clear the headphones pairing history
 - After power on, hold BOTH +& - for 5 seconds till LED blinks RED & BLUE twice. Then release the buttons and the headphones enter into pairing mode automatically.

- Visit [YouTube.com/Avantree](https://www.youtube.com/Avantree) ANC032 to see how-to videos.

For more detailed information please search ANC032 on support.avantree.com or contact support@avantree.com directly.