

User Manual


Stereo Wireless Headphones

AH6B










Product Overview	1
Basic Operation	1
Status of LED indicators	2
Connect to a Bluetooth device	2
Connect to two Bluetooth devices simultaneously	3
Reconnect to Bluetooth device	3
Connect to PC / Laptop	3
Using as a wired headphone	4
Charging	4
Reset	4
Troubleshooting	4

Product Overview



Basic Operation

Button	Function	Operation
Power Switch ⌘ 🔴 ● ⚪	Power ON	Slide the power switch towards middle 🔴 ● ⚪ you'll hear "Welcome to Avantree"
	Pairing	Slide the power switch to left 🔴 ● ⚪ and hold for 3 seconds. You'll hear "Pairing" and the LED indicator blinks RED and BLUE alternately.
	Power OFF	Slide the power switch to right 🔴 ● ⚪ you'll hear "Good Bye"
📞	Answer / End a call	Press 📞 once
	Reject a call	Hold 📞 1s whilst a call coming
	Activate smart voice assistant	Press 📞 twice
	Micropahone Mute ON/OFF	While on an active call, Press and hold 📞 1s to activate/close Microphone Mute function. You'll hear "Microphone Mute ON/OFF"
⏮	Track backward	Press ⏮ once
⏸	Play/Pause	Press ⏸ once
⏭	Track forward	Press ⏭ once

Volume Wheel 	Volume up	Rotate the volume wheel forward  to volume up
	Volume down	Rotate the volume wheel backward  to volume down
	Microphone Mute ON/OFF	While on an active call with boom mic, Press and hold  1s to activate/close Microphone Mute function. You'll hear "Microphone Mute ON/OFF"
	Voice Prompt ON/OFF	Hold  till you hear "Voice Prompt ON/OFF"


Note: Functionality varies by application.

Status of LED indicators

Working Status	LED indicator
Paring Mode	Blinks BLUE & RED alternately
Reconnecting	Blinks BLUE once every 1 second
Disconnected	Blinks BLUE once every 10 seconds
Microphone Mute ON	Remains RED
Connected	Blinks BLUE once every 5 seconds
Low battery	Blinks RED three times every 10 seconds


Connect to a Bluetooth device

Enter Headphones into Pairing Mode:

Slide the power switch to left  and hold for 3 seconds. You'll hear "Pairing" and the LED indicator blinks **RED** and **BLUE** alternately.

Pair to mobile device


- Set the headphones into Pairing Mode as above.
- Activate Bluetooth on your phone and set it to search for new devices.
- Select "Avantree AH6B", once successfully paired you'll hear "connected".



Connect to two Bluetooth devices simultaneously


To add another cell phone

- Connect with the FIRST phone as above, then turn off the headphones.
- Connect headphones with SECOND phone as above.
- Tap and select "Avantree AH6B" on the FIRST phone. Now, Avantree AH6B connected with TWO phones simultaneously.




Reconnect to Bluetooth device

Reconnection

Normally, when the next time you turn on Avantree AH6B, it will automatically reconnect the last paired device. Alternatively, Slide the power switch to left *  once, then release to enter into its Reconnection Mode.

Connect to PC / Laptop

- Set the headphones into Pairing Mode as above.
- Activate Bluetooth function on your PC/Laptop, search & select "Avantree AH6B" to pair and connect.
- For music stream, please set "Avantree AH6B" as the Playback Default Device/ Out put device in Sound Setting page.
- For Skype call, please set "Avantree AH6B Hands-free Headset" as microphone and speaker device in Audio Settings.



Using as a wired headphone

Use the supplied 3.5mm audio cable to connect to a non-Bluetooth audio device, or if the headphone battery is depleted.

Note: The headphone will power off automatically once you plug in the 3.5mm audio cable.

Charging

When the LED flashes RED 3 times per 10 seconds or you hear the voice prompts “Low battery please turn off and charge”, you should fully recharge the device for about 2 hours. Charged with the micro USB cable - The LED indicator on the headphones will remain **RED** while charging and turn off when charging is complete.

Reset

Clear pairing history

If you have issues with the audio stream skipping or cutting out when using Avantree AH6B, please try to clear pairing history as following:

Firstly, turn on the headset (Non-calling Status), then Press and Hold BOTH  & 

5 seconds till the LED blinks PINK for 2 seconds, then the headphones enter into PAIRING MODE automatically.

Troubleshooting

No sound with PC?

- Set Avantree AH6B as the default device or output device on the PC.
- When using AH6B to make VOIP calls through apps, please set “AH6B Hands-Free” as Microphone and Speakers device.

No sound with Bluetooth transmitter to watching TV?

- Ensure Bluetooth transmitter and headphones are connected properly.
- Check to ensure audio source is functioning properly
 - AUX & RCA output on TV – test with wired headphones
 - OPT output on TV – Set audio format to “PCM/LPCM” or turn off Dolby/DTS
- Change your TV audio out setting to External speakers / Headset.

Headphones do not pair with Bluetooth device?

- Ensure AH6B is in Pairing mode – LED will flash BLUE and RED alternately.
- For Bluetooth transmitter, ensure the transmitter is in Pairing mode – refer to its user manual.
- For Smart phone, tablet and PC
 - Turn the Bluetooth off and then on again.
 - Delete “Avantree AH6B headphones” from your devices Bluetooth list and then try to pair again.
- Clear the headphones pairing history and pair again.