


User Manual


Wireless Earbuds for Sport

BTHS-134




Product Overview	1
How to wear?.....	1
Basic operation.....	3
LED indicator status	3
Connect to mobile device	4
Connect with 2 mobile devices simultaneously	5
Reconnect.....	6
Charging	7
Clear pairing history / Reset	8
Troubleshooting.....	8

Product Overview



How to wear?

Choose suitable size




Fitting method




Wear the headset

Drape the headset cord behind your neck and attach the clothing clip to the back of your shirt to maximize fit and stability for headphone.



Another option for improving fit and stability is to cinch the excess cord up into a loop with the clip instead of attaching it to your clothing



Basic operation

FUNCTION	OPERATION
General	
Power ON	Press & hold  for about 3 seconds until LED illuminates BLUE for about 1s.
Power OFF	Press & hold  for about 3 seconds until LED illuminates RED for about 1s, then goes off.
ENTER PAIRING MODE	From off status,press & hold  for about 5 seconds until LED flashes BLUE and RED alternately.
Reconnect	Press  once
Music control	
Play / pause music	Press  once
Volume up / down	Short press + or -
Next / previous track	Long press + or -
Call control	
Answer / end a call	Press  once
Reject a call	Long press  for 2 seconds in a call
Active Voice Assistant - Siri / Google Assistant (Phone feature)	Once connected, double click 


LED indicator status

Headset Status	LED indicators
Ready to pair	Flashes BLUE and RED alternately
Connected	Flash BLUE twice every 4 seconds
Disconnected	Flash BLUE once every 2 seconds
Battery low	Flash RED 4 times every minute
Charging	Solid RED
Fully charged	RED light turns off



Connect to mobile device

1. **Note:** The HS134 will enter pairing mode when powered on for the **FIRST TIME**.
After that, set the headset to **PAIRING MODE** if you need connect to a **NEW** device.



- **Set headset to PAIRING MODE** - From off status, hold **Ⓞ** for about 5 seconds until LED flashes **BLUE** and **RED** alternately.



- Activate Bluetooth on your device; search and select “Avantree HS134” to connect.





- Once connected, LED will flash **BLUE** twice every 4s, you will hear a voice prompt “Connected”. Now you can stream audio.




Connect with 2 mobile devices simultaneously



- Pair & connect with the first device following the above guides.
- Turn off the Bluetooth of the first device.



- Repeat steps in above "Connect to mobile device" section to add the second device.




- Turn on the Bluetooth of first device. Then connect the HS134 on the device manually.




Note: This only works for two mobile devices simultaneously, such as mobile phones and tablets; not for PCs or Bluetooth transmitters.

Reconnect

Normally, when turning HS134 on, it will automatically reconnect to the **LAST CONNECTED** device. If not, please click © once or select "Avantree HS134" on your Bluetooth device to manually reconnect.




OR




Charging

When the LED flashes RED and you hear the “battery low” prompt, you should fully recharge the HS134 for about 90 minutes. The LED will remain RED while charging and turn off when it is full.




You can plug it into a USB wall charger (DC 5V / 0.5-2A) or computer USB port that is powered on.



Clear pairing history / Reset


From off status, press & hold  for about 10 seconds. **DO NOT RELEASE** until LED flashes **RED** 3 times slowly. It will power off thereafter. The HS134 will enter pairing mode automatically next time you turn it on.



Troubleshooting

Headphones do not pair with Bluetooth device?

- Ensure the HS134 is in Pairing mode – LED will flash **BLUE** and **RED** alternately.
- For Smart phone, tablet and PCs
 - Turn the Bluetooth off and then on again.
 - Delete “Avantree HS134” from your device Bluetooth list and then try to pair again.



- Clear the headphones pairing history and pair again.

Sound cuts in & out?

Ensure your mobile device is not in a metal case and placed on the right side of your body. Otherwise, Bluetooth cross-body issues may cause poor reception, which may cause sound cuts in and out.

