
6500 DW Hi-Hat Stand



6500 DW Hi-Hat Stand

Part Number	Description
DWSP003	.168 Heel clip Hi hats & pedals-no plate
DWSP100	RUBBER STABILIZER 4pk w/hole 1.25 in ea.
DWSP133	UPPER ROD FOR 6500
DWSP344	HI HAT ADJUSTMENT NUT
DWSP353	DW WING SCREW, 8MM
DWSP356	FELT WASHER (hi hat seat)
DWSP363	LOWER SPRING ROD
DWSP365	PLASTIC BUSHING FOR 3/4 IN TUBE JOINT
DWSP366	6 INCH HH SPRING WITH STEP WASHER
DWSM379	STANDARD HI HAT CLUTCH
DWSP381	METAL WASHER FOR HH CYMBAL SEAT
DWSP390	CLUTCH BODY
DWSP391	CLUTCH NUT
DWSP393	CLUTCH NUT, LARGE
DWSP487	5/8 inch memory lock for 6000 stands
DWSP701	BACK HEEL SCREW (3 pack)
DWSP704	10-24x7/8 SCREW AND NUT FOR HI HAT CHAIN
DWSP730	CLAMP SCREW FOR TUBE JOINT,TOP TIER 3/4
DWSM1207	DELTA II BEARING HINGE
DWSP2003	1/4-20 SQ.HEAD SCREW (TECH LOCK) 4 PACK
DWSP2004	6MM HI-HAT CLUTCH DRUM KEY SCREW
DWSP2008	WING NUT FOR Hi-Hat CYMBAL SEAT (4 PACK)
DWSP2009	6MM WING SCREW FOR CLUTCH (4 PACK)
DWSP2014	FELT WASHER FOR CLUTCH (4 PACK)
DWSP2051	FOOT, RUBBER W/SPIKE & SPRING, FOR 6500
DWSP2118	UPPER TUBE AND CYMBAL SEAT FOR 6500
DWSP2143	DELTA HEEL CASTING W/ SLOPE (5000) 2009
DWSP0026	FOOTBOARD FOR 6000_X PEDAL

Note: Some of the screws on the pedal have been treated with a chemical lock to prevent unwanted loosening during playing. In order to loosen the chemical lock holding these screws, you may first need to heat them with a hair dryer for 2-3 minutes.

