Instruktion för anslutning av Wallbox till Heartbeat

1. Inställningar i Wallbox-portalen
    a. Logga in i Wallbox-appen
    b. Uppdatera mjukvara till senaste uppdatering, 6.4.14 eller senare





1KOM
MA5°


wallbox
Chargers
Commander 2 SN 936394
DISCONNECTED
Update
Restart
Overview
Users
Sessions
Settings
Monthly insights
February 2024
Energy supplied
57.265 kWh
Charging time
5h 42m
Sessions
1
Energy cost
SEK 11.45
Now
Disconnected
Charger not connected to the network
Grid
0 kW
Vehicle
Green
Report
Custom
Today
7D
1M
3M
6M
12M
Energy supplied
Charging time
Sessions
Energy cost
Income
Line
Linear
Day
Settings
Power
Power limit
32A
MID Power meter
Disabled
Energy management
Power Sharing
ORGANIZATIONS
Family
Organizations
SECTIONS
Dashboard
Chargers
Locations
Sessions
Users
Payments
Help
Settings
Andreas Börjesson


wallbox
Chargers
Commander 2 SN 949018
LOCKED
Update
Restart
Overview
Sessions
Settings
General
Charger's name
Location
Power limit
Timezone
Connectivity
OCPP
Payments
Energy cost
Software
Auto-update
General
Charger's name
Commander 2 SN 949018
Edit
Location
Family
Change location
Power limit
19A
Edit
Timezone
Europe/Berlin
Edit
Connectivity
OCPP WebSocket connection
Allow third-party management
ORGANIZATIONS
Family
Organizations
SECTIONS
Dashboard
Chargers
Locations
Sessions
Users
Payments
Help
Settings



c. Tillåt OCPP i Wallbox-portalen



d) Mata in IP-adress för GridX Box från IP-scanningen i Wallbox-portalen. Din IP-adress får du från supporten på 1KOMMA5°.

Exempel: **ws://192.168.0.1:8180/ocpp**



e) Välj "Wallbox" och klicka Save



f. Meddela sedan 1KOMMA5° för att genomföra en ny scanning av systemet.