Sonus faber

ARTISAN OF SOUND

APP

WIRELESS SPEAKER APPLICATION

OWNER'S MANUAL

CONTENTS

1 PRE CONDITIONS 3

2 GETTING STARTED 3

3 SETUP 4

4 CHOOSE THE MUSIC - Streaming Platforms 6

5 CHOOSE THE MUSIC - Bluetooth 7

6 CHOOSE THE MUSIC - Analogue-HDMI-Optical 8

7 EXPLORE THE SOUND - Home 9

8 EXPLORE THE SOUND - Home-Equalizations 9

9 EXPLORE THE SOUND - Settings 10

10 CONTROL MULTIPLE Sonus faber DEVICES 12

1 PRE CONDITIONS

Make sure Sonus faber product is present and close to Wi-Fi router.
Make sure Control line is blinking white.
See Owner's Manual on www.sonusfaber.com

Make sure Wi-Fi connection is active.
Make sure Bluetooth is active.
Make sure any Connection Adaptation/ Management options are not active.

2 GETTING STARTED

Available on the App Store

GET IT ON Google Play



3 SETUP

1



2

3



4

5

6*



7

8

9



10

*If the operation is not successful on the first attempt, repeat the procedure.

3 SETUP





11



12



13

4 CHOOSE THE MUSIC

Streaming Platforms



1



2



3



4



5

5 CHOSE THE MUSIC

Bluetooth



1



2



3

4

6 CHOSE THE MUSIC

Analogue - Hdmi - Optical





7 EXPLORE THE SOUND
Home



8 EXPLORE THE SOUND
Home - Equalizations



9 EXPLORE THE SOUND
Settings



1



2



Customize your product name



1



2



Set your product placement for the best reproduction in your room

9 EXPLORE THE SOUND
Settings



1



2



Set your product to match perfectly with other devices that is connected to



1



2



Keep your product updated or perform factory reset

9 EXPLORE THE SOUND
Settings







1

2

Additional customizable settings

10 CONTROL MULTIPLE Sonus faber DEVICES
iOS







1

2

3

10 CONTROL MULTIPLE Sonus faber DEVICES

Android

GET IT ON Google Play

Google Home

1



2



3



4



5



6

Sonus faber S.p.A.
Via Meucci, 10 - 36057 Arcugnano (VI) - Italy
Tel. +39 0444/288788 - info@sonusfaber.com