


RUNNING BOARD

Components:



Hardware:



M8 x 30MM Hex
Head Bolts
Qty 16



M8 Flange Lock
Nuts
Qty 8



M8 Flat
Washers
Qty 16



Nylon
Washers
Qty 8



M8 Lock
Washers
Qty 16




Weld
Support
Qty 8




M8 U Nut
Clip
Qty 8

1. Remove all contents from the package and check stainless steel running boards for any damage. Also, verify that all components and hardware listed above are included before you begin installation.


2. Begin installation on passenger's side of vehicle.




2. Install the M8 U Nut Clips into the holes in the Rocker Panel as shown (3a and 3b). Some vehicles may have threaded inserts in the Rocker Panel already. If so, please disregard the M8 U Nut Clip. Install these U Nut Clips so that the threads are to the inside of the rocker panel. Be careful not to drop the



3. Align the Brackets up with the U Nut Clips or the pre-threaded holes in the Rocker Panel.



4. Fasten the Front Bracket using one (1) M8 Flange Lock Nut, one (1) Weld Support, one (1) Nylon Washer and one (1) M8 x 30MM Hex Head Bolt. Repeat for Center and Rear Brackets.



5. Complete the Front Bracket installation by fastening with one (1) M8 x 30MM Hex Head Bolt, one (1) M8 Lock Washer and one (1) M8 Flat Washer. Repeat for Center and Rear Brackets. When all hardware is in place, everything must be tightened. See Page 1 for Torque Specifications.

