

# 8. Pair and Connect two Devices Simultaneously

## <u>In\_TX\_mode</u>

1) Pair with the first device by following the previous instructions in the "Use as a Transmitter (TX mode)" section.

- 8 -

- 2) Pair with the second device
- Set second headphones/speaker to pairing mode. • Set Oasis to pairing mode again, press the 🛞 button for 3s until the TX LED
- flashes GREEN and WHITE.
- Wait until connected. Once Oasis connected to two devices, you will see LEDs A and B both illuminated.

#### Notes:

1) For improved compatibility and sound quality, we suggest that you use Bluetooth devices with CSR chipset, e.g. Avantree Audition Pro, Plantronics

- 12 -

2) When using dual-link, Oasis doesn't support aptX low latency

#### 11. Troubleshooting

backbeat pro. etc.

- 1) I am having trouble pairing and connecting to my Bluetooth device.
- Please check the following:
- 1. Your wireless device supports the wireless profiles listed in the specifications.
- 2. Oasis and your device are next to each other or within 3 feet / 1 meter. 3. Make sure both Oasis and the wireless device are in pairing mode.
- 2) After connecting and pairing with my wireless device, I cannot hear any music from my sound system 1. Make sure you select the correct audio input mode (AUX/OPT) by short
- pressing the 🗲 button.
- 2. Make sure to remove the protective head on optical cable.
- 3. In Optical mode, Oasis support device with sampling rate under 48kHz

- 16

12. Warnnings

pairing)

In RX mode

Receiver (RX mode)" section

flashes GREEN and WHITE

A and B both illuminated.

device to play on the other.

2) Pair with the second device

## Avantree Technology CO.,Ltd. The 4th Floor, Yurpeng Building, NO.1019 Jiabin Rd, Luohu District, Shenzhen,

Guangdong, China. This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may

1) Pair with the first device by following the previous instructions in the "Use as a

• Set Oasis to pairing mode again, press the 🛞 button for 3s until the RX LED

· Wait until connected. Once Oasis connected the two devices, you will see LEDs

· Active Bluetooth on the second device to find "Avantree Oasis" to connect.

Note: Only one device can play music at any time. You must stop the music on one

- 13 -

not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,

- 17 -

- pairing).

aptX<sup>®</sup> Low Latency Avantree Oasis is a wireless long range audio transmitter & receiver incorporating the To take advantage of the better performance of the APTX Low Latency Codec, latest "AptX low-latency" technology for CD-like quality sound with virtually no delay. the other side device must support the same codec. If the other side device only Multifunctional, supporting optical, bypass and voice prompts. Providing the best supports the normal AptX codec, or the SBC one, those codecs will be used instead. solution to enable your TV or home audio system to wirelessly stream hi-fi audio Audio delay when paired with different headphones/receiver-The audio delay will be Headphones/receiver support -~ 40ms aptX Low Latency codec ~ 70ms aptX codec SBC codec (most standard Bluetooth audio) ~ 220ms - 3 -4. LED indications Slide to "Bluetooth" to power on & ente Bluetooth mode. Slide to "Bypass" to power on & enter Slide to " ()" to turn off the device. Enter paring mode Hold this button for about 3 seconds. Short press once Short press once to switch between AUX (3.5mm) and Optical audio mode Voice prompt on/off Hold for 3 seconds to switch Voice on/off. In AUX audio mode, short press once (OPT mode doesn't support) In AUX audio mode, short press once. (OPT mode doesn't support) Details see next page. Transmitter mode Slide to TX to enter transmitting mode. Slide to RX to enter receiving mode. - 7 -7. Bypass mode (Non-Bluetooth) Bypassing means using Oasis as a non-Bluetooth device which connects the TV 1) Connect your speaker to Oasis "RX Output" port with the audio cable provided and speaker via wires directly. This design enables you to switch between wired (Bypass mode) and wireless (Bluetooth mode) with just one switch without the need 2) Connect Oasis to a power source with USB cable and adapter. to disconnect any cables. 1) Connect audio source (TV, DVD etc.) to Oasis "TX Input" port with the audio 5) Select the correct audio input mode (AUX/OPT) by short pressing the 🕀 cables provided (optical or AUX/ RCA). 2) Connect your speaker to Oasis "RX Output" port with your own audio cable 6) Pairing - Pair Oasis with your Bluetooth-enabled phone/PC/tablet. (optical or AUX/RCA). • Set Oasis into pairing mode, RX LED flash GREEN / WHITE alternately fast. 3) Connect Oasis to a power source with USB cable and adapter. - First-time use: Oasis will auto enter pairing mode (with clear memory). 4) Slide the Power/Mode switch to the "Bypass" position. 5) Select the correct audio input/output mode (AUX/OPT) by short pressing • Active Bluetooth on your phone or another device to find "Avantree Oasis" to the 🔄 button. (Important Note: Bypass for AUX to AUX & OPT to OPT only). · Wait and connected (For quick pairing, better keep them within 1 meter when 6) Ready for use. - 10 -- 11 -**10. Product Specifications** 9. Restore Factory Default Settings BT version: 4.1 You may need to reset Oasis if it is not working as expected. When Oasis is reset to Supports profiles: A2DP, AVRCP factory default settings, all the paired device information will be cleared • Audio codec: AptX, AptX-LL, SBC 1) Slide Power/Mode switch to the "Bluetooth position". Operational range: Class I, up to 50 meters 2) Make sure Oasis is not connected to any Bluetooth devices - LEDs A and B should Input voltage/ current: Micro USB DC5.0V== 500mA both be off. Operating temperature:-10°C ~ 45°C 3) Press and hold the  $\oplus$  and  $\bigcirc$  buttons together until you hear voice prompt • Storage temperature: -20°C ~ 60°C "pairing history cleared". Support sampling rate in optical mode: ≤48KHz Product size: 114×75×30mm Product weight: 90g - 14 -- 15 may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. M Avantree -- Consult the dealer or an experienced radio/TV technician for help. To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator Need help? your body: Use only the supplied antenna. - FAQ: support.avantree.com - Live chat: www.avantree.com (5:00 pm-1:00 am PST) Email: support@avantree.com  $\mathbf{C} \in \mathbf{O}$ Video user guide for Oasis on Youtube.com www.avantree.com Telephone support: +1 408 600 0579 (CET 8am-3pm) the latest provisions. support@avantree.com +1 800 232 2078 (PST 9am-5pm +86 755 82285022 (CST 9am-6pm) - 18 -Z-PKMN-T500-V0

Dispose of the packaging and this product in accordance with



